

A List of Our Laptop Replacement Keyboards We Sell:

<p>Acer Aspire5810T</p>	<p>Acer Aspire 5810 series, 5810T series, 5410 series, 5410T series, 5536 series, 5536G series, 5738 series, 5739 series, 5739G series, 5740 series, 5740G series, 7535G series, 5236 series, 5242 series, 5538 series, 5538G series, 5738DG series, 5738DZG series, 5738G series, 5738PG series, 5738PZG series, 5738Z series, 5738ZG series, 5810TG series, 5810TZ series, 5810TZG series, 7535 series, 7735 series, 7735G series, 7735Z series, 7735ZG series, 7736 series, 7736G series, 7736Z series, 7736ZG series, 7738 series, 7738G series, 5338 series, 5340 series, 7336 series, 5542 series, 5542G series, 5740DG series, 5741 series, 5741G series, 5741Z series, 5741ZG series, 7340 series, 7340G series, 7740 series, 7740G series</p> <p>Acer Travelmate 8571T Series, 8571G Series, 8571 Series</p>
<p>Acer Extensa5210</p>	<p>Acer Travelmate 5330 series, 4320 series, 4330 series, 4430 series, 4520 series, 4525 series, 4530 series, 4720 series, 4730 series, 4730G series, 5220 series, 5220G series, 5310 series, 5310G series, 5320 series, 5320G series, 5520 series, 5520G series, 5530 series, 5710 series, 5710G series, 5720 series, 5720G series, 7320 series, 7520 series, 7720 series, 7720G series</p> <p>Acer Extensa 4120 series, 4220 series, 4230 series, 4420 series, 4430 series, 4620 series, 4620Z series, 4630 series, 5120 series, 5210 series, 5220 series, 5420 series, 5420Z series, 5430 series, 5610 series, 5620 series, 5620G series, 7620 series, 7620Z series</p> <p>Acer eMachines D620 series</p>

Acer aspire one 532H	<p>Acer Aspire One AO532H Series, AO532H-2406 Series, AO532H-2527 Series, AO532H-2742 Series, AO532H-2789 Series, 521 Series, 533 Series, D255 Series, D260 Series, PAV70 NAV70 Series, 532 Series, 532H Series,</p> <p>Acer Emachine 350 Series, eM350 Series, NAV51 Series</p>
Acer aspire one 751	<p>Acer Aspire 1410 Series (11.6"), 1430 Series, 1430Z Series, 1551 Series, 1810 Series, 1810T Series, 1810TZ Series, 1830 Series, 1830T Series, 1830TZ Series, 3935 Series,</p> <p>Acer Aspire One 721 Series, 751 Series, 751h Seires, 751h-1021, 751h-1080, 751h-1211, 751h-1259, 751h-1273, 751h-1279, 751h-1346, 751h-1351, 751h-1401, 751h-1522, 751h-1534, 751h-1611, 751h-1893, 751h-1948, AO721 Series</p> <p>Acer TravelMate 8172 Series, 8172T Series, 8172Z Series</p>
Acer eMachines E525	<p>Acer Aspire 5241 series, 5332 series, 5334 series, 5516 series, 5516-5063, 5516-5474, 5517 series, 5517-1208, 5517-1216, 5517-1643, 5517-5078, 5517-5086, 5517-5358, 5517-5535, 5517-5661, 5517-5671, 5517-5689, 5517-5700, 5517-5997, 5532 series, 5534 series, 5541 series, 5541G series, 5732 series, 5732Z series, 5732ZG series, 5734 series, 5734Z series, 7315 series, 7715 series, 7715Z series</p> <p>Acer eMachines E430 Series, E527 Series, E637 Series, E727 Series, eM-E430 Series, eM-E525 Series, eM-E625 Series, eM-E627 Series, eM-E628 Series, eM-E630 Series, eM-E725 Series, eM-G525 Series, eM-G625 Series, eM-G725 Series</p>
Acer Travelmate 4520	<p>Acer Extensa 4120 Series, 4220 Series, 4230 Series, 4420 Series, 4430 Series, 4620 Series, 4620Z Series, 4630 Series, 5120 Series, 5210 Series, 5220 Series, 5420 Series, 5420Z Series, 5430 Series, 5610 Series, 5620 Series, 5620G Series, 7620 Series, 7620Z Series</p> <p>Acer Travelmate</p>

		<p>4320 Series, 4330 Series, 4430 Series, 4520 Series, 4525 Series, 4530 Series, 4720 Series, 4730 Series, 4730G Series, 5220 Series, 5220G Series, 5310 Series, 5310G Series, 5320 Series, 5320G Series, 5330 Series, 5520 Series, 5520G Series, 5530 Series, 5710 Series, 5710G Series, 5720 Series, 5720G Series, 7320 Series, 7520 Series, 7720 Series, 7720G Series</p> <p>Acer eMachines D620 Series</p>
Asus	50/70	<p>Asus K50 series, K50AB series, K50AD series, K50AF series, K50C series, K50IN series, K50IJ series, P50 series, P50IJ series, K51 series, K60 series, K61 series, K62 series, K70 series, K70IJ series, K72 series, F52 series, F52q series, F90 series, X5D series, X5DC series, X5DI series, X5AC series, F52A series, K50AE series, K50ID series, K50IE series, K50IL series, K50IP series, K51AB series, K51AC series, K51AE series, K51IO series, K60IJ series, K60IL series, K60IN series, K61IC series, K62F series, K62Jr series, K70AB series, K70AC series, K70AD series, K70AE series, K70AF series, K70IC series, K70ID series, K70IL series, K70IO series, K72DR series, K72DY series, K72F series, K72JB series, K72Jk series, K72Jr series, K72JT series, K72JU series, X5DIJ series</p>
Asus	50/70	<p>Asus K50 Series, K50AB Series, K50AD Series, K50AF Series, K50C Series, K50IN Series, K50IJ Series, P50 Series, P50IJ Series, K51 Series, K60 Series, K61 Series, K62 Series, K70 Series, K70IJ Series, K72 Series, F52 Series, F52q Series, F90 Series, X5D Series, X5DC Series, X5DI Series, X5AC Series, F52A Series, K50AE Series, K50ID Series, K50IE Series, K50IL Series, K50IP Series, K51AB Series, K51AC Series, K51AE Series, K51IO Series, K60IJ Series, K60IL Series, K60IN Series, K61IC Series, K62F Series, K62Jr Series, K70AB Series, K70AC Series, K70AD Series, K70AE Series, K70AF Series, K70IC Series, K70ID Series, K70IL Series, K70IO Series, K72DR Series, K72DY Series, K72F Series, K72JB Series, K72Jk Series, K72Jr Series, K72JT Series, K72JU Series, X5DIJ Series,</p>
Asus	G73	<p>Asus A52 series, A52B series, A52BY series, A52D series, A52DY series, A52Dr series, A52F series, A52J series, A52JB series, A52JC series, A52JE series, A52JK series, A52JR series, A52JT series, A52JU series, A52JV series, A52N series, F50 series,</p>

		<p>F50Q series, F50S series, F50SF series, F50SL series, F50SV series, F50Z series, F70 series, F70SL series, G51 series, G51J series, G51Jx series, G51V series, G51Vx series, G53 series, G53JW series, G53SW series, G53SX series, G60 series, G60J series, G60Jx series, G60Vx series, G72 series, G72Gx series, G73 series, G73GH series, G73J series, G73Jh series, G73Jw series, G73S series, G73SW series, K52 series, K52DY series, K52De series, K52Dr series, K52F series, K52J series, K52JB series, K52JK series, K52JK series, K52JR series, K52JT series, K52JU series, K52JV series, K52Jc series, K52Je series, K52N series, K53 series, K53E series, K53SC series, K53SD series, K53SJ series, K53SK series, K53SM series, K53SV series, K53TK series, N50 series, N50V series, N50VC series, N50VG series, N50VN series, N51 series, N51A series, N51T series, N51TE series, N51TP series, N51V series, N51VF series, N51VG series, N51VN series, N52 series, N52D series, N52DA series, N52Jv series, N53 series, N53DA series, N53J series, N53JF series, N53JG series, N53JL series, N53JN series, N53JQ series, N53NB series, N60 series, N60DP series, N61 series, N61DA series, N61J series, N61Ja series, N61Jq series, N61Jv series, N61V series, N61VF series, N61VG series, N61VN series, N61W series, N70 series, N70SV series, N71 series, N71J series, N71JA series, N71JQ series, N71JV series, N71V series, N71VG series, N71VN series, N73 series, N73J series, N73JF series, N73JG series, N73JN series, N73JQ series, N73S series, N73SM series, N73SV series, N90 series, N90SC series, N90SV series, P52 series, P52F series, P52Jc series, P53 series, P53E series, P53E-1A series, P53SJ series, P53SJ-1AL series, U50 series, U50A series, U50F series, U50V series, U50VF series, U50Vg series, UL50 series, UL50A series, UL50AG series, UL50AT series, UL50V series, UL50VF series, UL50VG series, UL50VT series, UX50 series, UX50V series, X52 series, X52DE series, X52F series, X52J series, X52JR series, X61 series, X61Gx series, X61Q series, X61S series, X61SF series, X61SL series, X61SV series, X61Z series</p>
Dell	E6400	<p>Dell Latitude E5400 series, E5410 series, E5500 series, E5510 series, E6400 series, E6410 series, E6500 series, E6510 series</p> <p>Dell Precision M2400 series, M4400 series, M4500 series</p>
Dell	1545	Dell Inspiron

	1545, 1420, 1520, 1525, 1526, 1546, 1521, 1318 Dell Vostro 1400, 1500, 1540 Dell XPS M1530, M1330
Dell D600	Dell Inspiron 500m Series, 510m Series, 600m Series, 8500 Series, 8600 Series, 9100 Series Dell Latitude D500 Series, D505 Series, D600 Series, D505, D800 Dell Precision M60 Dell XPS Generation 1
Dell Vostro 1510	Dell Vostro 1510, 1320, 1310, 1520
Dell Studio 1535	Dell Inspiron 1435 Series Dell Studio 15 series, 1535 series, 1536 series, 1537 series, 1555 series, 1557 series, 1558 series, PP33L
Dell 14R	Dell Inspiron 14R Series, 14V, 14V Series, N4010 Series, N4020 Series, N4030 Series, N5030, M5030
Dell D620	Dell Latitude D620, D620 ATG, D630, D630 ATG, D630N, D630c, D820, D830, D830N, PP04X, PP18L Dell Precision M4300, M65, PP04X
Compaq 620	Compaq 620 Series, 621 Series HP 620 Series, 625 Series
Compaq CQ60	Compaq G60 Series, G60-121WM, G60-230US, G60-235DX, G60-

	<p>237US, G60-243DX, G60-249WM, G60-440US, G60-441US, G60-442OM, G60-443CL, G60-445DX, G60-453NR, G60-458DX, G60T Series,</p> <p>Compaq Presario CQ60 Series, CQ60-100 Series, CQ60-101XX, CQ60-102XX, CQ60-103XX, CQ60-200 Series, CQ60-202US, CQ60-203NR, CQ60-204NR, CQ60-206US, CQ60-210US, CQ60-212US, CQ60-215DX, CQ60-220US, CQ60-224NR, CQ60-249US, CQ60-300 Series, CQ60-410US, CQ60-417DX, CQ60-418DX, CQ60-419WM, CQ60-42, CQ60-420, CQ60Z Series, CQ60Z-200</p>
<p>Compaq CQ61</p>	<p>Compaq G61 Series, G61-100 Series, G61-200 Series, G61-300 Series, G61-300CA, G61-304NR, G61-306NR, G61-320CA, G61-320US, G61-321NR, G61-322NR, G61-323CA, G61-327CL, G61-329CA, G61-336NR, G61-429WM WM961UA, G61-438NR WJ498UA, G61-439NR WJ499UA, G61-511WM, G61-631NR WA970UA, G61-632NR WA969UA,</p> <p>Compaq Presario CQ61 Series, CQ61-100 Series, CQ61-200 Series, CQ61-300 Series, CQ61-303XX, CQ61-310US, CQ61-313NR, CQ61-313US, CQ61-314US, CQ61-319WM, CQ61-320CA, CQ61-324CA, CQ61-410US, CQ61-411WM, CQ61-412NR, CQ61-414NR, CQ61-420US, CQ61-429US, CQ61z-300 CTO, CQ61z-400 CTO</p>
<p>Compaq CQ62</p>	<p>Compaq G56 Series, G56-100 Series, G56-100XX MV IUR XM761AS, G56-122US XG722UA, G56-123NR XG601UA, G56-125NR XG770UA, G56-126NR XG771UA, G56-127NR XG773UA, G56-128CA XG604UA, G56-129WM XG598UA, G56-141US XG603UA, G62 Series, G62-101XX WH387AS, G62-103XX WL726AS, G62-134CA WA903UA, G62-140US WA904UA, G62-143CL WA906UA, G62-144DX WA912UA, G62-145NR, G62-147NR WQ436UA, G62-149WM WQ434UA, G62-153CA WQ433UA, G62-154CA WA907UA, G62-200XX MV IUR WW842AS, G62-201XX MV IUR WU752AS, G62-208CA XA505UA, G62-219CA XB094UA, G62-219WM WQ760UA, G62-220CA WQ841UA, G62-220US WQ761UA, G62-221CA XB064UA, G62-222US WQ847UA, G62-223CA XA506UA, G62-223CL WQ765UA, G62-224CA XB061UA, G62-224HE WQ848UA, G62-225DX WQ762UA, G62-225NR WQ769UA, G62-</p>

226NR XB091UA, G62-227CA XB062UA, G62-227CL WQ844UA, G62-228CA XA503UA, G62-228CL WQ766UA, G62-228NR XB066UA, G62-229NR XB067UA, G62-231NR XB068UA, G62-233NR XB095UA, G62-234DX XB093UA, G62-236NR XB092UA, G62-237CA WQ767UA, G62-237US XD041UA, G62-238A WQ763UA, G62-238NR XD042UA, G62-244CA XB065UA, G62-251XX MV IUR WU756AS, G62-264CA XA504UA, G62-320CA XH057UA, G62-323CA XH067UA, G62-325CA XH077UA, G62-327CA XH061UA, G62-339WM XH058UA, G62-340US XH066UA, G62-341NR XH070UA, G62-343NR XH071UA, G62-346NR XH073UA, G62-347CL XH054UA, G62-347NR XH075UA, G62-348CA XH072UA, G62-348NR XG956UA, G62-352NR XG941UA, G62-353NR XG942UA, G62-354CA XG952UA, G62-355CA XX384UA, G62-355DX XH068UA, G62-357CA XG953UA, G62-358CA XG950UA, G62-358NR XG955UA, G62-359CA XG946UA, G62-363NR XU418UA, G62-365CA XH065UA, G62-a00 Series, G62-b00 Series, G62t-100 CTO VK734AV, G62t-100 CTO VK735AV, G62t-100 CTO VU636AV, G62t-100 CTO VU637AV, G62t-100 CTO VU667AV, G62t-250 CTO WF946AV, G62t-350 CTO WV773AV,

Compaq Presario

CQ56 Series, CQ56-100 Series, CQ56-100XX XM762AS, CQ56-104CA XG823UA, CQ56-109WM XG635UA, CQ56-110US XG636UA, CQ56-115DX XG809UA, CQ56-122NR XG646UA, CQ56-124CA XG682UA, CQ56-129NR XG683UA, CQ56-134CA XG638UA, CQ56-148CA XG818UA, CQ56-154CA XG639UA, CQ56-201NR XY872UA, CQ56-204CA LG540UA, CQ56-219WM XY871UA, CQ56-220CA XZ013UA, CQ56-240CA XZ014UA, CQ62 Series, CQ62-200 Series, CQ62-200CA WQ852UA, CQ62-209CA XA501UA, CQ62-209WM WQ849UA, CQ62-210US WQ775UA, CQ62-211HE WQ858YA, CQ62-213NR WQ857UA, CQ62-214NR WQ779UA, CQ62-215DX WQ856UA, CQ62-215NR WQ782UA, CQ62-217CA WQ777UA, CQ62-219WM WQ778UA, CQ62-220US WQ850UA, CQ62-225NR XA500UA, CQ62-228DX XC432UA, CQ62-231NR XC434UA, CQ62-238DX XC433UA, CQ62-270TX, CQ62-271TX, CQ62-272TX, CQ62-273TX, CQ62-274TX, CQ62-277TX, CQ62-278TX, CQ62-280TX, CQ62-300 Series, CQ62-410US XG958UA, CQ62-411NR XG961UA, CQ62-412NR XZ271UA, CQ62-416NR XZ275UA, CQ62-417NR XZ272UA, CQ62-418NR XZ276UA, CQ62-419NR XZ196UA, CQ62-421NR XZ197UA, CQ62z-200 CTO

Compaq CQ71	<p>Compaq G71 Series, G71-329WM, G71-333 Series, G71-333CA, G71-333NR, G71-339CA, G71-340US, G71-343US, G71-345CL, G71-347CL, G71-349WM, G71-351CA, G71-358NR, G71-430CA, G71-437CA, G71-441NR, G71-442NR, G71-445 Series, G71-445US, G71-447US, G71-448CL, G71-449WM, G71t-300 CTO, G71t-300 Series, G71t-400 CTO, G71t-400 Series</p> <p>Compaq Presario CQ71 Series</p>
Compaq CQ72	<p>Compaq G61 Series, G61-100 Series, G61-200 Series, G61-300 Series, G61-300CA, G61-304NR, G61-306NR, G61-320CA, G61-320US, G61-321NR, G61-322NR, G61-323CA, G61-327CL, G61-329CA, G61-336NR, G61-429WM, WM961UA, G61-438NR, WJ498UA, G61-439NR, WJ499UA, G61-511WM, G61-631NR, WA970UA, G61-632NR, WA969UA,</p> <p>Compaq Presario CQ61 Series, CQ61-100 Series, CQ61-200 Series, CQ61-300 Series, CQ61-303XX, CQ61-310US, CQ61-313NR, CQ61-313US, CQ61-314US, CQ61-319WM, CQ61-320CA, CQ61-324CA, CQ61-410US, CQ61-411WM, CQ61-412NR, CQ61-414NR, CQ61-420US, CQ61-429US, CQ61z-300 CTO, CQ61z-400 CTO</p>
Compaq C700	<p>Compaq Presario C700, C700 Series, C700T, C700XX, C706NR, C712NR, C713NR, C714NR, C715NR, C717NR, C727, C727US, C729, C730, C751NR, C762NR, C764NR, C768CA, C769US, C769US, C770US, C771US, C776NR, C777CL, C777NR</p>
HP 530	<p>HP 510 Series, 530 Series</p>
HP 6710b	<p>HP Business Notebook 6710b Series, 6710s Series, 6715b Series, 6715s Series</p>
HP DM3-1000	<p>HP DM3 Series, DM3-1000 Series, DM3-1020CA, DM3-1023CA, DM3-1024CA, DM3-1030US, DM3-1030WM, DM3-1035DX, DM3-1040US, DM3-1044NR, DM3-1047CL, DM3-1047NR, DM3-1053XX, DM3-1058NR, DM3-1100 Series, DM3-1124CA, DM3-1130US, DM3-1131NR, DM3-1140US, DM3-1148LA, DM3T-1000 CTO, DM3T-1100 CTO, DM3Z-1000, DM3Z-1100 CTO</p>
HP DV7-4000	<p>HP Pavilion</p>

		DV7-4000 series, DV7-4051NR, DV7-4053CL, DV7-4060US, DV7-4061NR, DV7-4065DX ,DV7-4069WM, DV7-4070US, DV7-4071NR, DV7-4073NR, DV7-4077CL, DV7-4080US, DV7-4083CL, DV7-4087CL, DV7-4151NR, DV7-4153CL, DV7-4157CL, DV7-4165DX, DV7-4169WM, DV7-4170US, DV7-4171US, DV7-4173US, DV7-4177NR, DV7-4178NR, DV7-4179NR, DV7-4180US, DV7-4182NR, DV7-4183CL, DV7-4190US, DV7-4191NR, DV7-4197CL, DV7-4263CL, DV7-4267CL, DV7-4269WM, DV7-4270US, DV7-4272US, DV7-4273US, DV7-4274NR, DV7-4276NR, DV7-4277NR, DV7-4278NR, DV7-4280US, DV7-4283CL, DV7-4285DX, DV7-4287CL, DV7-4289US, DV7-4290US, DV7-4292NR, DV7-4293NR, DV7-4294NR, DV7-4295US, DV7-4296NR, DV7-4297CL, DV7-4313CL, DV7t-4000 CTO, DV7t-4100 CTO
HP	DV7-1000	<p>HP Pavilion</p> <p>DV7-2000 Series, DV7-2019, DV7-2040, DV7-2040US, DV7-2043, DV7-2043CL, DV7-2044, DV7-2078, DV7-2078CA, DV7-2100 Series, DV7-2111US, DV7-2157, DV7-2170, DV7-2170US, DV7-2173, DV7-2173CL, DV7-2174, DV7-2177, DV7-2177CL, DV7-2180, DV7-2180US, DV7-2185DX, DV7-2185DX, DV7-2270US, DV7-2273CA, DV7-2273CL, DV7-2277CL, DV7-2278CA, DV7-2301NR, DV7-3000 Series, DV7-3057NR, DV7-3060US, DV7-3061NR, DV7-3063CL, DV7-3065DX, DV7-3067CL, DV7-3067NR, DV7-3069WM, DV7-3074CA, DV7-3078NR, DV7-3079WM, DV7-3080CA, DV7-3080US, DV7-3085DX, DV7-3089NR, DV7-3098CA, DV7-3100 Series, DV7-3160US, DV7-3162NR, DV7-3163CL, DV7-3164CL, DV7-3165DX, DV7-3166NR, DV7-3169WM, DV7-3171NR, DV7-3173NR, DV7-3180US, DV7-3183CL, DV7-3183NR, DV7-3186CL, DV7-3187CL, DV7-3188CL, DV7T-2000, DV7t-2000, CTO DV7t-2200 CTO, DV7t-3000 CTO, DV7t-3100 CTO, DV7t-3100 Series, DV7t-3300 CTO</p>
HP	NX7300	<p>HP Business notebook</p> <p>NX7400, NX7420, NX7300, NX7440, NX7410</p> <p>HP HSTNN Family</p> <p>HSTNN-104C</p>
HP	DV6000	<p>HP Pavilion</p> <p>dv6880ef, dv6622eb, dv6000, dv6880ee, dv6730ed, dv6700, dv6875eg, dv6570ed, dv6500, dv6875ca, dv6000t, DV6-6105sd, dv6874ca, dv6710, DV6-6100 series, dv6872la, dv6248eu, dv6097ea, dv6870us, dv6136ea, dv6095ea,</p>

dv6870ew, dv6088ea, dv6870el, dv6871us, dv6087ea, dv6870ei, dv6815ed, dv6086ea, dv6870eg, DV6772EG, dv6067ea, dv6870ee, dv6715, dv6065ea, dv6868ez, dv6699ed, dv6064ea, dv6865el, dv6617ed, dv6063ea, dv6864ca, DV6605, dv6062ea, dv6860ew, dv6545eg, dv6061ea, dv6860ep, dv6500t, dv6060, dv6860el, dv6239eu, dv6059ea, dv6860ei, dv6214ea, dv6058ea, dv6858ca, dv6201eu, dv6058cl, dv6855ez, dv6153eu, dv6057ea, dv6855el, dv6137eu, dv6054ea, dv6855eg, dv6135ea, dv6045us, dv6855ee, dv6060ea, dv6045nr, dv6855ea Special Edition, dv6023ea, dv6040us, dv6854ca, dv6040ca, dv6853ea, dv6985se, dv6025ea, dv6853cl, dv6920ed, dv6024ea, dv6853ca, dv6920ea, dv6022ea, dv6850ew, dv6915nr, dv6021ea, dv6850es, DV6910us, dv6020ea, dv6850er, dv6910ed, dv6019ea, dv6850ep, dv6908em, dv6018ea, dv6850el, dv6900 series, dv6017ea, dv6850ek, dv6899ea Special Edition, dv6016ea, dv6850ei, dv6899ea, dv6015ea, dv6850ee, dv6898es, dv6014ea, dv6850ec, dv6898ca, dv6013ea, dv6847tx, dv6895et, dv6012ea, dv6846tx, dv6894ca, dv6011ea, dv6845tx, dv6890ew, dv6010ea, dv6845eo, dv6890et, dv6007ea, dv6844tx, dv6890es, dv6006ea, dv6844ez, dv6887eo, dv6005ea, dv6844el, dv6885se, dv6004ea, DV6-6150sd, dv6885ek, dv6003xx, DV6-6150ed, dv6884ca, dv6003ea, DV6-6171sd, dv6883cl, dv6002xx, DV6-6105ed, dv6880se, dv6001xx, DV6-6170sd, dv6880ew, dv6001ea, DV6-6170ed, dv6880es, dv6000z, DV6-6171ed, dv6880el, dv6000 series, DV6000 CTO Notebook PC, DV6100 CTO, DV6100 Notebook PC, DV6100 Series, DV6102OD, DV6103NR, DV6105CA, DV6105US, DV6107US, DV6108NR, DV6108US, DV6109OM, DV6110CA, DV6110US, DV6113CA, DV6113US, DV6115CA, DV6115NR, DV6118NR, DV6119US, DV6120CA, DV6120US, DV6125OM, DV6125SE, DV6128OD, DV6129US, DV6130CA, DV6130US, DV6131OD, DV6135CA, DV6135NR, DV6139US, DV6140CA, DV6140US, DV6149US, DV6150CA, DV6150US, DV6165CL, DV6171CL, DV6174CA, DV6174CL, DV6196XX, DV6197XX, DV6198XX, DV6200 Notebook PC, DV6200 Series, DV6300 Series, DV6400 Series, DV6500 Series, DV6600 Series, DV6700 Series, DV6800 Series, DX6600 CTO, DX6600 Series, DX6650US, DX6667CL, DX6697NR

Compaq Presario

	V3000, V3113TU
HP DV9000	<p>HP Notebook PC</p> <p>EW635AV, EW680AV, EW680AVR, EZ379AV, EZ379AVR, EZ452UA, EZ452UAR, EZ453UA, EZ453UAR, EZ456UA, EZ456UAR, EZ457UA, EZ457UAR, EZ458UA, EZ458UAR, EZ459UA, EZ459UAR, EZ460UA, EZ460UAR, EZ461UA, EZ461UAR, EZ462UA, EZ462UAR, EZ467UA, EZ468UA, EZ468UAR, EZ470UA, EZ470UAR, PK292AS, RE042PA, RE042PAR, RE043PA, RE131PA, RE131PAR, RE132PA, RE132PAR, RE369EA, RE370EA, RE370EAR, RE372EA, RE372EAR, RE373EA, RE373EAR, RE383EA, RE383EAR, RG136AS, RG139AS, RG335UA, RG335UAR, RG339UA, RG339UAR, RG340UA, RG340UAR, RG341UA, RG341UAR, RG343UA, RG343UAR, RG346UA, RG346UAR, RH283AS, RL766PA, RL766PAR, RQ877AS, RS554EA, RS554EAR, RS555EA, RS555EAR</p> <p>HP Pavilion</p> <p>DV9000, DV9000EA, DV9002ea, DV9003EA, DV9003tx, DV9004eu, DV9004tx, DV9005EA, DV9005tx, DV9006tx, DV9008NR, DV9009tx, DV9010US, DV9010tx, DV9011tx, DV9012tx, DV9013tx, DV9014ea, DV9014tx, DV9015EA, DV9015tx, DV9016EA, DV9016tx, DV9017ea, DV9017tx, DV9018ea, DV9019ea, DV9019tx, DV9020TX, DV9021TX, DV9022ea, DV9022tx, DV9024EA, DV9030EA, DV9035EA, DV9036EA, DV9037EA, DV9038EA, DV9039EA, DV9040EA, DV9040eu, DV9041EA, DV9042EA, DV9043EA, DV9045ea, DV9046ea, DV9048ea, DV9049EA, DV9050ea, DV9051EA, DV9052EA, DV9053EA, DV9055EA, DV9056EA, DV9057EA, DV9058EA, DV9059EA, DV9060EA, DV9060US, DV9061EA, DV9062ea, DV9063ea, DV9064EA, DV9065EA, DV9071ea, DV9073EA, DV9074CL, DV9074EA, DV9075EA, DV9075EU, DV9075la, DV9076EA, DV9076eu, DV9077EA, DV9077eu, DV9077eu, DV9078EA, DV9079EA, DV9080EA, DV9081EA, DV9082ea, DV9082eu, DV9083EA, DV9084EA, DV9085ea, DV9085eu, DV9086EA, DV9087ea, DV9088ea, DV9089EA, DV9090ea, DV9091EA, DV9092ea, DV9093EA, DV9093eu, DV9094EA, DV9095EU, DV9096EA, DV9096xx, DV9097EA, DV9099EA, DV9100 series, DV9200, DV9201tx, DV9202ea, DV9202tx, DV9205eu, DV9205us, DV9206TX, DV9206eu, DV9207TX, DV9208TX, DV9209tx, DV9210tx, DV9211EA, DV9211tx, DV9212ea, DV9212tx, DV9213EA, DV9213tx,</p>

	<p>DV9214ea, DV9214tx, DV9215tx, DV9216EA, DV9216TX, DV9217TX, DV9217ea, DV9218ea, DV9219EA, DV9220eu, DV9221ea, DV9232eu, DV9233eu, DV9237eu, DV9241EA, DV9243EA, DV9244EU, DV9244ea, DV9248ea, DV9252eu, DV9253EA, DV9254eu, DV9255ea, DV9260nr, DV9265EA, DV9266ea, DV9266eu, DV9267ea, DV9268ea, DV9269ea, DV9271EA, DV9272EA, DV9273EA, DV9274eu, DV9275ea, DV9276EA, DV9283ea, DV9285EA, DV9286ea, DV9288ea, DV9289EA, DV9291EA, DV9292eu, DV9293EA, DV9294EA, DV9294EU, DV9295EA, DV9295EU, DV9296EA, DV9296eu, DV9297ea, DV9299ea, DV9300, DV9301tx, DV9302tx, DV9303EU, DV9303tx, DV9304eu, DV9304tx, DV9305eu, DV9306tx, DV9307TX, DV9308EA, DV9308TX, DV9309EA, DV9309TX, DV9309eu, DV9310TX, DV9310ea, DV9310eu, DV9311EU, DV9311ea, DV9311tx, DV9312ea, DV9312tx, DV9313ea, DV9314EA, DV9315ea, DV9316ea, DV9317ea, DV9318ea, DV9319EA, DV9320EA, DV9321ea, DV9322ea, DV9324EA, DV9331eu, DV9332EU, DV9332ea, DV9337EU, DV9338EU, DV9340ea, DV9341EU, DV9342eu, DV9343eu, DV9344eu, DV9345eu, DV9346ea, DV9348ea, DV9350ea, DV9351ea, DV9361ea, DV9362ea, DV9363EA, DV9372EU, DV9374eu, DV9375eu, DV9377EA, DV9378ea, DV9379ea, DV9380EA, DV9381ea, DV9385ea, DV9389EA, DV9390EA, DV9391EU, DV9392EA, DV9393ea, DV9394EA, DV9395EA, DV9396EA, DV9397EA, DV9398EU, DV9398ea, DV9399EA, DV9400 series, DV9500 Series, DV9600 Series, DV9700 Series, DV9800 Series, DV9900 Series</p>
<p>HP DV6-1000</p>	<p>HP Pavilion DV6 Series, DV6-1000 Series, DV6-1001XX, DV6-1027NR, DV6-1030US, DV6-1036US, DV6-1050US, DV6-1053CL, DV6-1054CL, DV6-1100 Series, DV6-1122US, DV6-1200 Series, DV6-1230US, DV6-1234NR, DV6-1238NR, DV6-1240US, DV6-1243CL, DV6-1244SB, DV6-1245DX, DV6-1247CL, DV6-1250US, DV6-1253CL, DV6-1259DX, DV6-1263CL, DV6-1268NR, DV6-1280US, DV6-1300 Series, DV6-1334US, DV6-1350US, DV6-1351NR, DV6-1352DX, DV6-1353CL, DV6-1354US, DV6-1355DX, DV6-1359WM, DV6-1360US, DV6-1361SB, DV6-1362NR, DV6-1363CL, DV6-1375DX, DV6-1378NR, DV6-2000 Series, DV6-2043US, DV6-2044DX, DV6-2051XX, DV6-2057CL, DV6-2066DX, DV6-2088DX, DV6-2100 Series, DV6-2144NR, DV6-2150US, DV6-2151CL, DV6-2152NR, DV6-2155DX, DV6-2157SB, DV6-2157US, DV6-2157WM, DV6-</p>

		2158NR, DV6-2162NR, DV6-2170US, DV6-2171NR, DV6-2173CL, DV6-2180US, DV6-2182NR, DV6-2190US, DV6-2192NR, DV6T, DV6t-1100 CTO, DV6t-1200 CTO, DV6t-1300 CTO, DV6t-2000 CTO, DV6t-2300 CTO WM828AV, DV6z-1000 CTO, DV6z-1100 CTO, DV6z-2000 CTO, DV6z-2100 CTO
HP	DV6-3000	<p>HP Pavilion</p> <p>DV6-3000 Series, DV6-3001au, DV6-3001tx, DV6-3001xx, DV6-3002au, DV6-3002xx, DV6-3003tu, DV6-3003xx, DV6-3004ax, DV6-3004tx, DV6-3006ax, DV6-3006tu, DV6-3007ax, DV6-3008tx, DV6-3010us, DV6-3012he, DV6-3013cl, DV6-3013nr, DV6-3015tx, DV6-3016tx, DV6-3017nr, DV6-3019wm, DV6-3020us, DV6-3022us, DV6-3023nr, DV6-3023tx, DV6-3024tx, DV6-3025dx, DV6-3030us, DV6-3031nr, DV6-3031tx, DV6-3032nr, DV6-3033cl, DV6-3033he, DV6-3033tx, DV6-3034nr, DV6-3034tx, DV6-3035tx, DV6-3036tx, DV6-3037nr, DV6-3037sb, DV6-3037tx, DV6-3040tx, DV6-3040us, DV6-3041tx, DV6-3049tx, DV6-3050us, DV6-3051x, DV6-3053he, DV6-3053tx, DV6-3055dx, DV6-3100 Series, DV6-3108ca, DV6-3109ca, DV6-3114ca, DV6-3118ca, DV6-3120us, DV6-3121nr, DV6-3122us, DV6-3123cl, DV6-3124nr, DV6-3127dx, DV6-3129nr, DV6-3130us, DV6-3131nr, DV6-3132nr, DV6-3133nr, DV6-3134ca, DV6-3134nr, DV6-3138ca, DV6-3140us, DV6-3143ca, DV6-3143cl, DV6-3143us, DV6-3144ca, DV6-3145dx, DV6-3147ca, DV6-3147sb, DV6-3150us, DV6-3152nr, DV6-3153nr, DV6-3155dx, DV6-3158ca, DV6-3160us, DV6-3163cl, DV6-3167ca, DV6-3170ca, DV6-3174ca, DV6-3194ca, DV6-3200 Series, DV6-3210us, DV6-3212nr, DV6-3217cl, DV6-3223cl, DV6-3225dx, DV6-3227cl, DV6-3230us, DV6-3231nr, DV6-3232nr, DV6-3234nr, DV6-3236nr, DV6-3238nr, DV6-3240ca, DV6-3240us, DV6-3243cl, DV6-3250us, DV6-3257cl, DV6-3257sb, DV6-3259wm, DV6-3263cl, DV6-3264ca, DV6-3267cl, DV6-3268ca, DV6-3270ca, DV6-3275ca, DV6-3278ca, DV6-3280ca, DV6-3284ca, DV6-3287cl, DV6-4001xx, DV6-4051nr, DV6-4053ca, DV6T-3000 Series, DV6T-3100 Series, DV6T-3200 Series, DV6Z-3000 Series, DV6z-3100 Series, DV6z-3200 Series</p>
HP	ZE2000	<p>HP</p> <p>G3100, G3050EA, G5000, G3000</p> <p>HP Pavilion</p> <p>DV5000 CTO, DV5000EA DV5000 Series, DV5000T CTO, DV5001XX, DV5003CL, DV5017CL, DV5020CA, DV5020US,</p>

DV5029US, DV5030US, DV5035NR, DV5040US, DV5088XX, DV5099XX, DV5100 CTO, DV5110CA, DV5110US, DV5115NR, DV5116NR, DV5117CA, DV5117CL, DV5120US, DV5123CL, DV5129US, DV5130CA, DV5130US, DV5135NR, DV5139US, DV5140CA, DV5140US, DV5150US, DV5163CL, DV5167CL, DV5170US, DV5178US, DV5189XX, DV5190US, DV5196XX, DV5197XX, DV5198XX, DV5199XX, DV5200 CTO, DV5210CA, DV5210US, DV5215CA, DV5215US, DV5216CA, DV5216CL, DV5217CL, DV5218NR, DV5220CA, DV5220LA, DV5220US, DV5222NR, DV5223OM, DV5224NR, DV5225CA, DV5226CA, DV5229OM, DV5229US, DV5230CA, DV5230US, DV5234US, DV5235CA, DV5236OM, DV5237CA, DV5237CL, DV5240CA, DV5240US, DV5250CA, DV5250US, DV5298XX, DV5299XX, zx5280EA, zx5275US-PF101UAR, ZV5000, zx5275US-PF101UA, zx5275us, zx5275EA-PB912EA, zx5275EA, zx5273EA, zx5270EA-PB915EA, ZV6000, zx5270EA, zx5265EA-PB911EA, ze2000, zx5265EA, zx5260EA, ZX6000 series, zx5245US, zx5245EA-PB913EA, zx5245EA, zx5369CL-PL957UAR, zx5202xx, zx5369CL-PL957UA, zx5202US, zx5369cl, zx5201xx, zx5000, ZX5300, zx5201-PF853AS, ZV6020ea, zx5300, zx5201, dv5264ea, zx5295US-PL958UAR, zx5200xx, zx5295US-PL958UA, zx5200-PC718AV, zx5295us, zx5200-PC717AV, zx5295EA, zx5260EA-PB914EA, zx5290us, zx5200EA, zx5202US-PF854AS, zx5290EA, ZX5200 series, ZV6276ea, zx5280US-PF100UAR, zx5200, ZV6251ea, zx5280US-PF100UA, zx5190us, ZV6090ea, zx5171EA, zx5190EA, ZV6069ea, zx5170us, zx5180us, ZV6064ea, zx5170EA, zx5180EA, ZV6006us, ZV5132ea, zx5178EA, ZV5378ea, dv5000t, zx5178cl, ZV5202us

Compaq Presario

R4000, R3000, V5232EA, V5000, V5000T, V2000, R4221EA, C500, R3158IT, C300, R3000z, R3000AP, M2500 series, M2000, C570EA, C500EA, C300EU, V2035EA, zx5200-PC716AV

HP Business notebook

NX6125, nx9110, nx6125, NX9110, NX9105, NX9100

Acer Aspire

9100, 9100WLMi

Fujitsu Pa1510

Fujitsu Siemens Amilo

PA1510, PA2510, Pi1505, Pi1510, Pi2515

Fujitsu L7300	Fujitsu Siemens Amilo L7300
lenovo 3000 N200	Lenovo 3000 C100 Series, 3000 C200 Series, 3000 F31 Series, 3000 F41 Series, 3000 G230 Series, 3000 G430 Series, 3000 G450 Series, 3000 G455 Series, 3000 G530 Series, 3000 N100 Series, 3000 N200 Series, 3000 N220 Series, 3000 N430 Series, 3000 N440 Series, 3000 N500 Series, 3000 V100 Series, 3000 V200 Series, C460 Series, C461 Series, C462 Series, C466 Series, C467 Series Lenovo Ideapad Y410 Series, Y430 Series, Y510 Series, Y520 Series, Y530 Series
Lenovo G560	Lenovo G560 Series G565 Series
Samsung X418/X420	Samsung X418, X420-JA03NL, X420-JA02IT, X420-FA02BE, X420 Aura SU4100, X420-JA01NL, X420-FA01PL, X420-FA02NL, X420-JA01BE, X420-FA01NL, X420-JA02NL, X420-JA01, X420 Series
Samsung X520	Samsung X520
SamsungR509/R510	Samsung P510 series, P560 series, R510 series, R560 series, R60 series, R70 series
Samsung RV510	Samsung NP-R525 series, NP-R530 series, NP-R540 series, NP-R618 series, NP-R620 series, NP-R719 series, NP-R728 series, NP-RV510 series, R525 series, R528 series, R530 series, R540 series, R618 series, R620 series, R719 series, R720, R728 series, RV510 series, RV510-A04 series
Toshiba L500	Toshiba Equium L350 Series Toshiba Qosmio X505 Series A500 Series, A505 Series, A505D Series, L350 Series, L350-ST2121, L350-ST2701, L350-ST3701, L350-ST3702, L355 Series, L355-S7811, L355-S7812, L355-S7817, L355-S7822, L355-S7827, L355-S7828, L355-S7831, L355-S78312, L355-S7834, L355-S7835, L355-S7837, L355-S7900, L355-S7902, L355-S79023, L355-S7905, L355-S7907, L355-S7915, L355D

	<p>Series, L355D-S7809, L355D-S7810, L355D-S7813, L355D-S7815, L355D-S7819, L355D-S7820, L355D-S7825, L355D-S7829, L355D-S7832, L355D-S7901, L500 Series, L500-ST2521, L500-ST2522, L500-ST5505, L500D Series, L500D-ST2531, L500D-ST2532, L500D-ST5501, L500D-ST5506, L500D-ST5600, L505 Series, L505-S5964, L505-S5966, L505-S5967, L505-S5969, L505-S5971, L505-S5982, L505-S5984, L505-S5988, L505-S5990, L505-S5993, L505-S5995, L505-S5997, L505-S5998, L505-S5999, L505-S6946, L505-S6951, L505-S6953, L505-S6954, L505-S6955, L505-S6956, L505-S6959, L505-S6962, L505-SP6906A, L505-SP6906C, L505-SP6906R, L505-SP6934R, L505-SP6984A, L505-SP6984C, L505-SP6984R, L505-SP6985C, L505-SP6997R, L505-SP6998R, L505D Series, L505D-S5963, L505D-S5965, L505D-S5983, L505D-S5985, L505D-S5986, L505D-S5987, L505D-S5992, L505D-S5994, L505D-S5996, L505D-S6947, L505D-S6948, L505D-S6952, L505D-S6957, L550 Series, L550-ST2721, L550-ST2722, L550-ST5701, L550-ST5702, L550-ST5707, L555 Series, L555-S7916, L555-S7918, L555-S7929, L555-S7945, L555D Series, L555D-S7909, L555D-S7910, L555D-S7912, L555D-S7930, L555D-S7932, P300 Series, P300-ST3014, P300-ST3712, P300-ST6711, P300D Series, P300D-ST3711, P305 Series, P305-S8814, P305-S8820, P305-S8822, P305-S8823, P305-S8824, P305-S8825, P305-S8826, P305-S8830, P305-S8832, P305-S8837, P305-S8838, P305-S8842, P305-S8844, P305-S8848, P305-S8854, P305-S88541, P305-S8857, P305-S8904, P305-S89041, P305-S8906, P305-S8910, P305-S8915, P305-S89151, P305-S8920, P305-S8996E, P305-S8997E, P305-ST771E, P305D Series, P305D-S8816, P305D-S8818, P305D-S8819, P305D-S8828, P305D-S8829, P305D-S8834, P305D-S8836, P305D-S88361, P305D-S8845, P305D-S8900, P305D-S8903, P305D-S8995E, P500 Series, P500-ST5806, P500-ST6821, P500D Series, P505 Series, P505-S8011, P505-S8940, P505-S8941, P505D Series</p> <p>Toshiba Satellite Pro L350, L350-S1001V, L350-S1001X, L350-S1701</p>
<p>Toshiba c650</p>	<p>Toshiba Satellite C650 Series, C650-BT2N11, C650-BT2N13, C650-BT2N15, C650-ST2N01, C650-ST2NX1, C650-ST2NX2, C650-ST3NX1, C650D Series, C650D-BT2N11, C650D-BT2N13, C650D-BT2N15, C650D-ST2N01, C650D-ST2N02, C650D-ST2N03,</p>

C650D-ST2NX1, C650D-ST2NX2, C650D-ST3NX1, C650D-ST3NX2, C655 Series, C655-S5047, C655-S5049, C655-S5052, C655-S50521, C655-S5053, C655-S5054, C655-S5056, C655-S5060, C655-S5061, C655-S5068, C655-S5082, C655-S5090, C655-S5092, C655-S5113, C655-S51131, C655-S5118, C655-S5119, C655-S5129, C655-S5132, C655-S5137, C655-S5140, C655-S5141, C655-S5142, C655-S9510D, C655-S9520D, C655-S9521D, C655-S9530, C655-S9531D, C655-SP4132, C655-SP4163, C655-SP4164, C655-SP4168, C655-SP4169, C655-SP5018L, C655-SP5018M, C655-SP5019L, C655-SP5019M, C655-SP5030L, C655-SP6001L, C655-SP6001M, C655-SP6007L, C655-SP6007M, C655-SP6008L, C655-SP6008M, C655-SP6009L, C655-SP6009M, C655-SP6010L, C655-SP6010M, C655-SP6011L, C655-SP6011M, C655D Series, C655D-S5041, C655D-S5042, C655D-S5043, C655D-S5044, C655D-S5045, C655D-S5046, C655D-S5048, C655D-S5051, C655D-S5057, C655D-S5063, C655D-S5064, C655D-S5079, C655D-S5080, C655D-S5081, C655D-S5084, C655D-S5085, C655D-S50851, C655D-S50852, C655D-S50853, C655D-S50854, C655D-S5086, C655D-S5087, C655D-S5088, C655D-S5089, C655D-S5091, C655D-S5120, C655D-S5126, C655D-S5130, C655D-S5133, C655D-S5134, C655D-S5135, C655D-S5136, C655D-S5138, C655D-S5139, C655D-S5143, C655D-SP4131, C655D-SP4151, C655D-SP5003M, C655D-SP5024L, C655D-SP5024M, C655D-SP6004L, C655D-SP6004M, L650 Series, L650-BT2N15, L650-BT2N22, L650-BT2N23, L650-ST2G01, L650-ST2N03, L650-ST2N04, L650-ST2NX1, L650-ST3NX1, L650D Series, L650D-ST2N01, L655 Series, L655-S5058, L655-S5059, L655-S5060, L655-S5061, L655-S5062, L655-S5065, L655-S5065BN, L655-S5065RD, L655-S5065WH, L655-S5069, L655-S5071, L655-S5072, L655-S5073, L655-S5074, L655-S5075, L655-S5078, L655-S5078BN, L655-S5078RD, L655-S5078WH, L655-S5083, L655-S5096, L655-S5097, L655-S5098, L655-S5098BN, L655-S5098RD, L655-S5098WH, L655-S5099, L655-S5100, L655-S5100BK, L655-S5100BN, L655-S5100RD, L655-S5100WH, L655-S5101, L655-S5103, L655-S5105, L655-S5106, L655-S5106BN, L655-S5106RD, L655-S5106WH, L655-S5107, L655-S5108, L655-S5111, L655-S5112, L655-S51121, L655-S51122, L655-S5112BN, L655-S5112RD, L655-S5112WH, L655-S5114, L655-S5117, L655-S5144, L655-S5146, L655-S5147, L655-S5149, L655-S5149WH, L655-S5150, L655-S5153, L655-S5154, L655-

S5155, L655-S5156, L655-S5156BN, L655-S5156RD, L655-S5156WH, L655-S5157, L655-S5158, L655-S5160, L655-S5163, L655-S5165, L655-S5166WHX, L655-S5168, L655-SP6004L, L655-SP6004M, L655D Series, L655D-S5050, L655D-S5055, L655D-S5066, L655D-S5066BN, L655D-S5066RD, L655D-S5066WH, L655D-S5067, L655D-S5076, L655D-S5076BN, L655D-S5076RD, L655D-S5076WH, L655D-S5093, L655D-S5094, L655D-S5095, L655D-S5102, L655D-S5102BN, L655D-S5102RD, L655D-S5102WH, L655D-S5104, L655D-S5109, L655D-S5110, L655D-S5110BN, L655D-S5110RD, L655D-S5110WH, L655D-S5116, L655D-S5145, L655D-S5148, L655D-S5151, L655D-S5152, L655D-S5159, L655D-S5159BN, L655D-S5159RD, L655D-S5159WH, L655D-S5164, L655D-S5164BN, L655D-S5164RD, L655D-S5164WH, L655D-SP5010L, L655D-SP5010M, L655D-SP5012L, L655D-SP5012M, L655D-SP5014L, L655D-SP5014M, L655D-SP5160, L655D-SP6001L, L655D-SP6001M, L655D-SP6002L, L655D-SP6002M, L655D-SP6003L, L655D-SP6003M, L670 Series, L670-BT2N13, L670-BT2N22, L670-BT2N23, L670-ST2N01, L670D Series, L670D-BT2N22, L670D-ST2N01, L670D-ST2N02, L670D-ST2N03, L675 Series, L675-S7018, L675-S7020, L675-S7044, L675-S7048, L675-S7051, L675-S7062, L675D Series, L675D-S7012, L675D-S7013, L675D-S7014, L675D-S7015, L675D-S7016, L675D-S7017, L675D-S7019, L675D-S7022, L675D-S7040, L675D-S7040GY, L675D-S7042, L675D-S7046, L675D-S7047, L675D-S7049, L675D-S7050, L675D-S7052, L675D-S7053, L675D-S7060, L750 Series, L750-BT4N22, L750-ST4N02, L750-ST4NX1, L750-ST5N02, L750-ST5NX2, L750-ST6N01, L750D Series, L750D-BT5N11, L750D-BT5N22, L750D-ST4N01, L750D-ST5NX1, L750D-ST6NX1, L755 Series, L755-S5103, L755-S5107, L755-S5151, L755-S5152, L755-S5153, L755-S5154, L755-S5156, L755-S5158, L755-S5166, L755-S5167, L755-S5168, L755-S5169, L755-S5170, L755-S5173, L755-S5175, L755-S5213, L755-S5214, L755-S5216, L755-S5239, L755-S5242, L755-S5242BN, L755-S5242GR, L755-S5242RD, L755-S5242WH, L755-S5243, L755-S5244, L755-S5245, L755-S5246, L755-S5247, L755-S5248, L755-S5249, L755-S5252, L755-S5253, L755-S5254, L755-S5255, L755-S5256, L755-S5257, L755-S5258, L755-S5271, L755-S5273, L755-S5275, L755-S5277, L755-S5280, L755-S5281, L755-S5282, L755-S5306, L755-S5308, L755-S5311, L755-S5349, L755-S5350, L755-S5351, L755-S5353, L755-S5354, L755-S5355, L755-

	<p>S5356, L755-S5357, L755-S5358, L755-S5360, L755-S5362, L755-S5364, L755-S5365, L755-S5366, L755-S5367, L755-S5368, L755-S9510BN, L755-S9510D, L755-S9510RD, L755-S9511BN, L755-S9511D, L755-S9511RD, L755-S9512BN, L755-S9512D, L755-S9512RD, L755-S9512WH, L755-S9513BN, L755-S9513RD, L755-S9520D, L755-S9530D, L755-S9530WH, L755-S9531RD, L755-S9532RD, L755-SP5101CL, L755-SP5102CL, L755-SP5167CM, L755-SP5168CM, L755-SP5169LM, L755-SP5174RM, L755-SP5175LM, L755-SP5203CL, L755-SP5279LM, L755-SP5291LM, L755D Series, L755D-S5104, L755D-S5150, L755D-S5160, L755D-S5162, L755D-S5164, L755D-S5204, L755D-S5218, L755D-S5227, L755D-S5241, L755D-S5250, L755D-S5251, L755D-S5279, L755D-S5347, L755D-S5348, L755D-S5359, L755D-S5361, L755D-S5363, L755D-SP5165RM, L755D-SP5166FM, L755D-SP5171LM, L755D-SP5172LM, L755D-SP5178LM, L770 Series, L770-BT4N22, L770-BT4NX1, L770-BT5NX2, L770-BT6NX1, L770D Series, L770D-BT5N11, L770D-BT5N22, L770D-ST4N01, L770D-ST5NX1, L770D-ST6NX1, L775 Series, L775-S7105, L775-S7130, L775-S7140, L775-S7240, L775-S7241, L775-S7243, L775-S7245, L775-S7248, L775-S7250, L775-S7307, L775-S7309, L775-S7350, L775-S7352, L775-S7355, L775D Series, L775D-S7110, L775D-S7132, L775D-S7135, L775D-S7206, L775D-S7210, L775D-S7220, L775D-S7220GR, L775D-S7222, L775D-S7223, L775D-S7224, L775D-S7226, L775D-S7228, L775D-S7304, L775D-S7305, L775D-S7330, L775D-S7332, L775D-S7335, L775D-S7340, L775D-S7345, c660</p> <p>Toshiba Satellite Pro C650 Series, C650-EZ1511, C650-EZ1512, C650-EZ1513, C650-EZ1515D, C650-EZ1521, C650-EZ1523, C650-EZ1524, C650-EZ1533, C650-EZ1534, C650-SP4166, C650-SP4166M, C650-SP5016L, C650-SP5016M, C650-SP6002L, C650-SP6002M, C650-Z2510T, L670 Series, L670-EZ1710, L670-EZ1711, L670-EZ1712, L670-EZ1715D</p>
Toshiba A200	Toshiba Satellite A200 series, A205 series, A210 series, A215 series