

**A List of Our Laptop Replacement Screens We Sell:**

<p>8.9" 1024*600 PIXELS 40 PIN WSVGA LED</p>	<p><b>Acer Aspire One</b> ZG5, A150 Series, A150, A110 Series, A110, A150-BW, A150-BB1, A150-BW-512, A110X, A150X, A150-BK-6L, A150-BGB, A150-BB-512, A150-BB-1GB, A150-AB, A150-1447, A150-1049, A110L, A110-AGB, A150L, A150-BW-1GB, A150-BP-1GB, A150-BK1, A150-BGB-1GB, A150-AW-1GB, A150-AB-1GB, A150-1983, A150-1570, A150-1532, A150-1493, A150-1382, A150-1249, A110-BGB, A110-BB, A110-AW, A110-AB, A110-1948, A110-1812, A110-1722, A110-1698, A110-1691, A110-1686, A110-1295, A110-1112</p> <p><b>Asus Eee PC</b> 901, 901-N437, 901-N270</p> <p><b>Packard Bell Dot</b> ZG5</p> <p><b>HP Mini</b> 2133</p> <p><b>Sony VAIO</b> PCG-C1 series, PCG-C1VM, PCG-C1XS, PCG-C1XG, PCG-C1X, PCG-C1MV, PCG-C1C, PCG-C1XF, PCG-C1XE, PCG-C1XD, PCG-C1XA, PCG-C1VE, PCG-C1MZX, PCG-C1F, C1XS PictureBook, C1 PictureBook, PCG-C2GPS, PCG-C1XG/BP, PCG-C1VSX/K, PCG-C1VS/BW, PCG-C1VRX/K, PCG-C1VR/BP, PCG-C1VPK, PCG-C1VP, PCG-C1VN, PCG-C1VJ/BP, PCG-C1VJ, PCG-C1VG, PCG-C1VFK, PCG-C1S, PCG-C1R, PCG-C1MWP, PCG-C1MW1, PCG-C1MW, PCG-C1MVPM, PCG-C1MVP, PCG-C1MVM, PCG-C1MVC, PCG-C1MSX, PCG-C1MRX, PCG-C1MR/BP, PCG-C1MHP, PCG-C1MGP, PCG-C190G, C1VPK PictureBook, C1VP PictureBook, C1VN PictureBook</p> <p><b>MSI Wind</b></p>
--	---

	<p>U90X-037EU, U90X, U90</p> <p><b>Dell Inspiron</b> Mini 9n</p>
<p>10.1" 1024*600 PIXELS 40 PIN WSVGA GLOSSY LED</p>	<p><b>Acer Aspire One</b> D250 Series, D250, D250-0BK, ZG8, D250-0BB, D250-1613, D250-HDTW, D250-BW, D250-BK, D250-ODW, D150-BTR</p> <p><b>Asus Eee PC</b> 1008HA</p> <p><b>Dell Inspiron Mini</b> 1012</p> <p><b>Compaq Mini</b> CQ10-501SD, CQ10 series, CQ10-400SD, 110c-1110SD, CQ10-700SD, CQ10-450SB, CQ10-110SG</p> <p><b>HP Mini</b> 110-3101sd, 2140, 110-1150ED, 110-3000sd, HP Mini 5102, 210-2003ed, 210-2002ed, 110-3150ed, 210-2001sd, 210-1102sd, 210-1099SE Vivienne Tam, 210-1103sd, 210-1100, 210-1000, 110-1001TU, 210-1190CA, 210-1040NR, 210 HD Edition, 110 Mi Edition, 5103, 210-2220sd, 210-1060sd</p> <p><b>Packard Bell Dot</b> s2.nl/407, sr.NL/100, sr.NL/305, sr.NL/098</p> <p><b>Samsung</b> N110, N150-HAV1BE, NC10, N150-JP01BE, N130-JA01DE, N150 Series, N110 Series, N210-JP01DE, N210 Series, N130 Series, N120 Series, N110-KA01BE, N150-HAV1NL, N110-KA01NL, N150-JP01NL, N150-JP05, N150-JA01, N150-JP02, N150-JAC1BE, N150-JA02BE, N150-JA01NL, N140-JA01, N140 Series, N120-JA01NL, N120, N150-JP03BE, N150-JP02NL, N150-JP02CA, N150-JP01, N150-JA04NL, N150-JA02NL, N130-KA03BE, N130-JA01BE, N130-JA01, N120-KA01NL, N120-KA01BE, NP Series, NP-R730, NP700G7A-S02, NP900X3A-A01, NP-R509, NP-P580, N145 Series, NP-NF110, NP-RF710, NP-RC510-S01, NP-R40, NP-P60, NP700G7A-S01, N145-JP02NL, NP-X60, NP-R65, N145-JP01NL, NP-P50, NP-SF311-S02, NP-RV711-A01, NP-RV511-S01, NP-RV511-A01, NP-RC710-S01, NP-P580-JA02, NF310-A03NL, NF310 Series, N145-JP02BE,</p>

	<p>N145-JP01, NP-SF311-S01, NP-RV511-A04, NP-RV511, NP-RF711-S01, NP-RC710-S02, NP-R45, NP-R40 Plus, NP-Q320H, NP-NC110-A04, NP-RV510-A01, NP-QX311-S01, NP-NC210-A02, NP-NC110-A03</p> <p><b>Toshiba</b>  NB200 Series, NB200, NB200-13P, NB200-10Z, NB200-12W, NB200-00P, NB200-00C, NB202-107, NB200-N313/P, NB200-N311/W, NB200-N310/BN, NB200-13L, NB200-131, NB200-12V, NB200-12U, NB200-12R, NB200-12N</p>
<p>10.1"  1024*600  PIXELS 40  PIN  GLOSSY  SLIM LED</p>	<p><b>Acer Aspire One</b>  521 Series, 532H Series, 521, 532h, 522 series, 532h-2Ds, 522, 522-C6Dkk, 532h-2Db, 522-C5Dkk, 533, 533 series, 532h-2Dr, 532h-2242, 532h-2067, 521-3782, 521-105Dcc, 521 Tigris, 521 -3089, 533-WBT, 532h-2730, 532h-2594, 532h-2309, 532h-2268, 532h-2206, 522-C5Grr, 521-3530, 521-105Dk_W7625, 521-105Dk, 533-N55Dww, 532h-2964, 532h-2825</p> <p><b>Asus Eee PC</b>  1000 series, 1000H, 1015, 1005HA, 1005P, 1000, 1005PX, 1015PX, 1015B, 1000HE, 1001HA, 1005, 1001PX, 1015PE, 1001PXD, 1011PX, 1008P, 1000HA, 1008HA, 1015PN, 1005PEG, 1005HAG, 1016P, 1015PEM, 1001P, 1000HG, 1000HD, 1016, 1015T, 1015PW, 1018P, 1015P, 1005HA-PU1X, 1005HA-P, 1005HA-H, 1005HAB, 1004DN, 1003HAG, 1000H-N437, 1000HG-N270, 1000HA-N270, 1015PED, 1015PD, 1011CX, 1011CX, 1005PR, 1005HR, 1005HE, 1005HA-VU1X-WT, 1005HA-VU1X-PI, 1005HA-VU1X-BU, 1005HA-VU1X-BK, 1005HA-VU1X, 1005HA-V, 1005HA-PU1X-BU, 1005HA-EU1X-BK, 1005HA-EU1X, 1005HA-E, 1005HA-A, 1005H, 1002SA, 1002HAE, 1002HA, 1001PQ, 1000-N270, 1000HV, 1000HD-CE900, 1000D</p>
<p>10.2"  1024*600  PIXELS 30  PIN  GLOSSY  WSVGA  LED</p>	<p><b>Asus Eee PC</b>  1000, 1000H, 1000HD, 1000HE, 1015PE</p> <p><b>Lenovo IDEAPAD</b>  S10</p> <p><b>MSI Wind</b>  U100, U100 Black, U100W-005, U100P-077NL, U100P-005, U100-444EU, U100-416EU, U100-415NL, U100-286EU, U100-261EU, U100-041EU, U100-021, U100-018EU, U100 Plus, U100 Love Edition</p> <p><b>Samsung NETBOOK</b>  SC10</p>

11.6"  
1366\*768  
PIXELS 40  
PINS WIDE  
GLOSSY  
LED

**Acer ASPIRE ONE**  
721-3070, 751H-1192

**Acer TIMELINEX**  
1830T

**Acer ZENBOOK**  
UX21, UX21-IE

**ASUS EEE PC**  
1101HA

**Benq JOYBOOK LITE**  
U121, U122

**Dell INSPIRON**  
1110, 11Z

**Gateway**  
LT31

**HP MINI**  
311

**HP PAVILION**  
DM1, DM1-1102SA

**Lenovo IDEAPAD**  
U160

**Lenovo THINKPAD**  
X100E

**Samsung**  
X125

**Sony VAIO**  
VGN-TT16GN, VGN-TT17GN

**Toshiba SATELLITE**  
T110D, T115D

11.6"  
1366\*768  
PIXELS 40  
PIN  
GLOSSY

**HP MINI**  
311, 311C

**HP PAVILION**

SLIM LED	DM1, DM1-1030, DM1-1035, DM1-2011, DM1-3100 series, DM1-1000 series, DM1-3200 series, dm1-3100er, DM1-4000 series, DM1-1100 series, DM1-4000sd, dm1-1020ed, DM1-4020sd, DM1-1120ed, DM1-1010ef, DM1-3221sd, dm1-3100sb, DM1-2000 series, DM1-3200sd, DM1-3200ed, dm1-3125ed, DM1-2100 series, DM1-4100 series, dm1-2010ed, dm1-4100ed, dm1-3125sd, dm1-3101eg, dm1-3100sa, dm1-2120ed, dm1-4110sd, dm1-4110ed, dm1-4100sd, DM1-2010so
12.1" 1366*768 PIXELS BIG 30 PIN GLOSSY WIDE LED	<p><b>ASUS</b> UL20A</p> <p><b>ASUS EEE PC</b> 1201, 1201N, 1201T, 1201HA, 1215</p>
13.3" 1366*768 PIXELS 40 PIN GLOSSY WIDE LED	<p><b>Acer Aspire</b> 3810T, 3810TG-944G50n, 3810T-XSH11, 3810T-354G32n, 3810T-H22F, 3935 series, 3810TZ-4880, 3810T-351G25, 3810TZ, 3810T-6376, 3935, 3810TZG-414G50n, 3810TZ-414G32n, 3810T-P22F, 3810T-H22X, 3810T-6415, 3935-864G25MN, 3935-744G25n, 3935-744G25MN, 3810TZG-414G32n, 3810TZG, 3810TZ-4806, 3810TZ-414G25N, 3810T-XSH11DOM, 3810T-S22F, 3810T-S22, 3810T-PH22X, 3810T-P22, 3810T-H22, 3810TG, 3810T-8737, 3810T-352G32na, 3810T-351G25N</p> <p><b>Acer Aspire Timeline</b> 3810T series, 3810TZ-414G64N, 3810TG-354G32N, Timeline 3810T, 3810TZ-414G50N, 3810TG-734G64N, 3810TG-944G50N, 3810T-944G32N, 3810T-353G25N, 3810TG-944G32n</p> <p><b>Acer TravelMate</b> 8371</p> <p><b>Acer ZENBOOK</b> UX31, UX31E</p> <p><b>Asus</b> UL30A-A1, UL30A-X1, UL30A-QX050C, UL30A-QX050V</p> <p><b>Dell STUDIO</b> XPS 13</p> <p><b>Dell VOSTRO</b> V3350, V3350-I5, V3350-I5-2430</p> <p><b>Gigabyte</b> M1305</p>

	<p><b>HP ProBook</b> 5310m</p> <p><b>Lenovo IDEAPAD</b> U350</p> <p><b>Samsung SERIES</b> 5</p> <p><b>Sony VAIO</b> VPC-S11X9E/B</p> <p><b>Toshiba Satellite</b> T130 series, T130-10V, T130-10T, T130-10G, T130-11N, T130-17C, T130-14T, T135</p>
<p>11.6" 1366*768 PIXELS 40 PIN GLOSSY SLIM LED</p>	<p><b>HP MINI</b> 311, 311C</p> <p><b>HP PAVILION</b> DM1, DM1-1030, DM1-1035, DM1-2011, DM1-3100 series, DM1-1000 series, DM1-3200 series, dm1-3100er, DM1-4000 series, DM1-1100 series, DM1-4000sd, dm1-1020ed, DM1-4020sd, DM1-1120ed, DM1-1010ef, DM1-3221sd, dm1-3100sb, DM1-2000 series, DM1-3200sd, DM1-3200ed, dm1-3125ed, DM1-2100 series, DM1-4100 series, dm1-2010ed, dm1-4100ed, dm1-3125sd, dm1-3101eg, dm1-3100sa, dm1-2120ed, dm1-4110sd, dm1-4110ed, dm1-4100sd, DM1-2010so</p>
<p>17.3" 1920*1080 PIXELS WUXGA FULL HD LED</p>	<p><b>Acer eMachines</b> G625-203G16Mi</p> <p><b>ASUS</b> G73, G74</p> <p><b>Fujitsu LIFEBOOK</b> NH751</p> <p><b>HP ELITEBOOK</b> 8760W</p> <p><b>Mecer</b> P170HM</p> <p><b>Sony VAIO</b> VPC-EC1M1E/WI</p> <p><b>Toshiba QOSMIO</b></p>

	X770, X770-11C
17.3" 1600*900 PIXELS 40 PIN GLOSSY WXGA++ HD+ LED	<p><b>Acer ASPIRE</b> 7250, 7530, 7535, 7535G, 7536ZG, 7540, 7730, 7735, 7736, 7736G, 7736Z, 7738, 7739, 7739G, 7750, 7750G</p> <p><b>Acer EMACHINES</b> G525, G625, G725</p> <p><b>Acer TRAVELMATE</b> 7750, 7750G</p> <p><b>ASUS</b> G72GX, K70AB, K72JR, N70SV, X70IC, X900</p> <p><b>Compaq PRESARIO</b> CQ71, CQ71-100, CQ71-105, CQ71-135, CQ71-140, CQ71-200, CQ71-314</p> <p><b>Dell ALIENWARE</b> M17, M17XR3</p> <p><b>Dell INSPIRON</b> 17, 1750, N7110</p> <p><b>Dell STUDIO</b> 1745, 1747</p> <p><b>Dell VOSTRO</b> V3750</p> <p><b>Dell XPS</b> 17, L702X</p> <p><b>Gateway</b> NV78, NV7802, NV79 NV7901 NV7902, NV7906, NV7915, NV7921, NV7922, NV7923, NV7925</p> <p><b>HP PAVILION</b> 1251, 1251SI, DQH562, DV7, DV7-6050, DV7-6050EI, DV7-6C50, DV7-6C50EI, DV7-6C51, DV7-6C51-EI, G7, G7-1270, G7-135 , G7-135SI, G71, G71-329, G71-333, G71-339, G71-340, G71-345, G71-347, G71T-300, QH562EA</p> <p><b>HP PROBOOK</b></p>

	<p>4410S, 4730S</p> <p><b>Mecer</b> W170HN, W270, W270ESQ</p> <p><b>Packard Bell EASYNOTE</b> MS2290</p> <p><b>Proline</b> W270HU</p> <p><b>Samsung</b> R720, R730, X900</p> <p><b>Toshiba SATELLITE</b> C670, C670-11W, L755, L755-14R, L770, L770-12X</p>
<p>13.3" 1280*800 PIXELS 20 PIN GLOSSY WXGA LCD</p>	<p><b>Apple MACBOOK</b> 9C5B, A1181, A1278, A1342, M403A, MA254, MA255, MA403, MA472, MA699, MA700, MA700X, MA701, MA702, MA703, MA704, MB061, MB062, MB063, MB064, MB065, MB157, MB158, MB402, MB403, MB404, MB881</p> <p><b>ASUS</b> F6, F6S, F6V, R1E, U3S, W6K00A, W7S-B1B</p> <p><b>Dell</b> C117J, CP695, CX060, D060J, D684C</p> <p><b>Dell INSPIRON</b> 1318</p> <p><b>Dell STUDIO XPS</b> 13, 1340, X1340</p> <p><b>Dell VOSTRO</b> 1310</p> <p><b>Dell XPS</b> 1340, M1330</p> <p><b>Fujitsu Siemens AMILO</b> SA-3650, SI-2636, SI-3655</p> <p><b>Fujitsu Siemens FMV-BIBLO</b></p>



MG18

**Fujitsu Siemens LIFE BOOK**

S2210, S6410, Sa3650, T1010, T5010

**LG XNOTE**

E300

**Sony VAIO**

PCG-CP1L, PCG-C190G, PCG-6J2M, PCG-6S1L, PCG-F630, PCG-XG18, PCG-XG28, PCG-XG38, PCG-XG500, PCG-XG9, VGN-C1, VGN-C140, VGN-C150, VGN-C190, VGN-C2, VGN-C240, VGN-C250, VGN-C51, VGN-C90, VGN-S1, VGN-S150, VGN-S170, VGN-S2, VGN-S200, VGN-S260, VGN-S270, VGN-S3, VGN-S36, VGN-S360, VGN-S380, VGN-S4, VGN-S430, VGN-S45, VGN-S46, VGN-S460, VGN-S470, VGN-S48, VGN-S480, VGN-S49, VGN-S5, VGN-S54, VGN-S550, VGN-S560, VGN-S570, VGN-S580, VGN-S660, VGN-S67, VGN-S73, VGN-S94, VGN-SZ1, VGN-SZ110, VGN-SZ120, VGN-SZ140, VGN-SZ160, VGN-SZ17, VGN-SZ170, VGN-SZ2, VGN-SZ210, VGN-SZ220, VGN-SZ230, VGN-SZ240, VGN-SZ25, VGN-SZ250, VGN-SZ270, VGN-SZ272, VGN-SZ28, VGN-SZ280, VGN-SZ281, VGN-SZ3, VGN-SZ320, VGN-SZ330, VGN-SZ340, VGN-SZ360, VGN-SZ370, VGN-SZ381, VGN-SZ390, VGN-SZ4, VGN-SZ420, VGN-SZ43, VGN-SZ430, VGN-SZ433, VGN-SZ440, VGN-SZ445, VGN-SZ450, VGN-SZ460, VGN-SZ470, VGN-SZ480, VGN-SZ491, VGN-SZ5, VGN-SZ53, VGN-SZ54, VGN-SZ55, VGN-SZ562, VGN-SZ58, VGN-SZ6, VGN-SZ60, VGN-SZ61, VGN-SZ62, VGN-SZ640, VGN-SZ645, VGN-SZ650, VGN-SZ660, VGN-SZ670, VGN-SZ680, VGN-SZ691, VGN-SZ7, VGN-SZ70, VGN-SZ71, VGN-SZ72, VGN-SZ73, VGN-SZ74, VGN-SZ750, VGN-SZ791, VGN-SZ83, VGN-SZ84, VGN-SZ91, VGN-SZ94

**Toshiba**

M800, M853

**Toshiba PORTEGE**

M800 series, M800-100, M800-101, M800-105, M800-106, M800-107, M800-116, M800-11E, M805, M805D, M801, M802, M803, M806, M807, M808, M810, M821, M822, M823, M825

**Toshiba SATELLITE**

U300, U305, U400 series, U400, U400-04W, U400-060, U400-061, U400-108, U400-10A, U400-10I, U400-10J, U400-10L, U400-10M, U400-10N, U400-100, U400-10T, U400-112, U400-11L, U400-11Q, U400-11T, U400-12R, U400-134, U400-144, U400-14B, U400-14M, U400-150, U400-151, U400-156, U400-157, U400-15E, U400-15X, U400-16B, U400-17R, U400-17V, U400-17Y, U400-18F, U400-18G, U400-216, U400-DW2, U400-DW3,

	<p>U400-ST5404, U400-136, U400-13T, U400-15G, U405, U405D, U405-S2920, U405-S2918, U405-S2882, U405-S2856, U405-S2854, U405-S2833, U405-S2830, U405-S2826, U405-S2824, U405-S2820, U405-S2817, U405D-S2918, U405D-S2910, U405D-S2874, U405D-S2852, U405D-S2850, U405D-S2848, U405D-S2846, U500, U505</p> <p><b>Toshiba SATELLITE PRO</b> U300, U400, U500</p> <p><b>Toshiba TERCA</b> 500, M8, M9</p>
<p>14.1" 1280*800 PIXELS GLOSSY WXGA LCD (WITH OR WITHOUT DELL INVERTER)</p>	<p><b>Acer Aspire</b> 5552, 3620 series, 3620, 5560 series, 3680 series, 4720Z, 5560, 5560G-6348G75MN, 5570 series, 3680, 5550 series, 3050 series, 4720 series, 5050 series, 3050, 3640 series, 3623WXM, 3600, 5570ANWXCi, 5051, 5050, 3630 series, 3600 series, 5560AWLMi, 5550, 5540 series, 5500 series, 5051AWXM, 4920 series, 1330, 2108, 2223, 2301, 2400, 2403, 2410, 2412, 2420, 2423, 2428, 2440, 2441, 2480, 2482, 2483, 2513, 2626, 2943, 2974, 3040, 3050, 3053, 3054, 3210, 3220, 3240, 3242, 3280, 3300, 3320, 3465, 3510, 3600, 3603, 3616, 3620, 3623, 3624, 3628, 3630, 3640, 3641, 3680, 3681, 3682, 3683, 3684, 3686, 4030, 4174, 4220, 4233, 4285, 4300, 4310, 4315, 4320, 4330, 4420, 4421, 4520, 4530, 4581, 4710, 4715, 4720, 4730, 4765, 4920, 4925, 5030, 5050, 5051, 5052, 5053, 5070, 5172, 5374, 5410, 5500, 5502, 5550, 5551, 5554, 5555, 5560, 5562, 5570, 5571, 5572, 5574, 5580, 5583, 5590, 5596, 5770, 5827, 5951, 8735, AS4920</p> <p><b>Acer Extensa</b> 5610 series, 5210-401G08MI, 5210-402G12MI, 2440, 4120, 4130, 4210, 4220, 4230, 4320, 4420, 4620, 4630</p> <p><b>Acer Emachines</b> D620, D520, E620, EMD620, N-10, N-12, N-14, N10, N12, N14, W340UA</p> <p><b>Acer FERRARI</b> 1000</p> <p><b>Acer Travelmate</b> 223X, 225XC, 2400, 2403, 2410 series, 2410, 2412, 2420, 2423, 2424, 2428, 2440, 2441, 2480, 2481, 2482, 2500, 3210, 3220, 3240, 3260, 3270, 3280, 3290, 3300, 3320, 3600, 3620, 4520, 4720, 5050, 5051, 529TXV, 6492, 6493, 6493</p> <p><b>Asus</b> N50 series, PRO50 series, N53SV, N53SV-SZ016V, A8 series, S6 series, N50VN, Pro55GL, N55SF, N53Jn, N50V, F8 series, PRO50RL, PRO59L-EP015C, PRO59L-AP014A, Pro59L, Pro55S-AP415C, PRO50VL, Pro50RL-</p>

AP240H, N55SF-S1060V, N53SV-SZ404V, M3 series, L8 series, Z6 series, W3 series, S6F Leather Collection, Pro52H, N55, N53SN, N53JQ-SZ191V, N53Jq, N53JF-SX091V, A8000F, L3800C, A6000, A8, A8J, A8JR, A8M, A8S, B80, F8, F80, F8P, F8SA, F8SV, S62, S62E, S62J, V2S, V2S, X80, Z62, Z70, Z99

**Dell**

500M, M9048, X160

**Dell INSPIRON**

1300, 1420, 1501, 1505, 630M, 640M, B120, B130, E1405, E1409, E1501, E1505, E1505N, PP21L

**Dell LATITUDE**

120L, 131L, D531, D620, D630, E5400, E6400

**Dell PRECISION**

M2400

**Dell VOSTRO**

1000, 1400, A840

**Dell XPS**

140M, M140

**Compaq**

500 Notebook PC, NW8440

**Compaq PAVILION**

DV2000

**Compaq PRESARIO**

CQ40, CQ45, M2000, M2200Z, R3000, V2000, V2009, V2010, V2030, V2035, V2069, V2140, V2150, V2200, V2205, V2220, V2239, V2300, V2306, V2312, V2400, V2405, V2600, V2602, V2608, V2615, V3000, V3001, V3002, V3003, V3004, V3005, V3006, V3007, V3008, V3009, V3010, V3011, V3012, V3013, V3014, V3015, V3016, V3017, V3018, V3019, V3020, V3021, V3022, V3024, V3025, V3026, V3027, V3028, V3029, V3030, V3031, V3032, V3033, V3034, V3035, V3036, V3037, V3038, V3039, V3041, V3042, V3043, V3044, V3045, V3046, V3047, V3048, V3049, V3050, V3051, V3052, V3053, V3054, V3055, V3056, V3057, V3058, V3059, V3060, V3061, V3062, V3063, V3064, V3065, V3066, V3067, V3069, V3071, V3072, V3100, V3101, V3102, V3103,

V3104, V3105, V3106, V3107, V3108, V3109, V3110, V3111, V3112, V3113, V3114, V3115, V3116, V3117, V3118, V3119, V3120, V3121, V3122, V3123, V3124, V3125, V3126, V3127, V3128, V3129, V3130, V3131, V3132, V3133, V3134, V3135, V3136, V3137, V3138, V3139, V3140, V3141, V3142, V3143, V3144, V3145, V3146, V3147, V3148, V3149, V3150, V3151, V3152, V3153, V3165, V3171, V3172, V3173, V3174, V3175, V3176, V3177, V3178, V3179, V3180, V3181, V3185, V3186, V3187, V3188, V3189, V3190, V3191, V3192, V3200, V3201, V3202, V3203, V3204, V3205, V3206, V3207, V3208, V3209, V3210, V3211, V3212, V3213, V3214, V3215, V3216, V3217, V3218, V3219, V3220, V3221, V3222, V3224, V3226, V3227, V3228, V3229, V3230, V3231, V3232, V3233, V3234, V3235, V3236, V3237, V3238, V3240, V3241, V3242, V3245, V3246, V3247, V3248, V3249, V3251, V3252, V3253, V3254, V3256, V3260, V3300, V3301, V3302, V3303, V3304, V3305, V3306, V3307, V3308, V3309, V3310, V3311, V3312, V3313, V3314, V3315, V3316, V3317, V3318, V3319, V3320, V3321, V3322, V3323, V3324, V3325, V3326, V3327, V3328, V3329, V3330, V3331, V3332, V3333, V3334, V3335, V3336, V3337, V3338, V3339, V3340, V3341, V3342, V3343, V3344, V3345, V3346, V3347, V3348, V3349, V3350, V3351, V3352, V3400, V3401, V3402, V3403, V3404, V3405, V3406, V3407, V3408, V3409, V3410, V3411, V3413, V3414, V3415, V3416, V3417, V3418, V3419, V3420, V3421, V3422, V3423, V3424, V3425, V3426, V3427, V3428, V3429, V3430, V3431, V3432, V3433, V3434, V3435, V3436, V3437, V3438, V3439, V3440, V3441, V3442, V3443, V3444, V3500, V3501, V3502, V3503, V3504, V3505, V3506, V3507, V3508, V3509, V3510, V3511, V3512, V3513, V3514, V3515, V3516, V3517, V3518, V3519, V3520, V3521, V3522, V3523, V3524, V3525, V3526, V3527, V3528, V3529, V3530, V3531, V3532, V3533, V3534, V3535, V3600, V3601, V3602, V3603, V3604, V3605, V3606, V3607, V3608, V3609, V3610, V3611, V3612, V3613, V3614, V3615, V3616, V3617, V3618, V3619, V3620, V3621, V3622, V3623, V3624, V3625, V3626, V3627, V3628, V3629, V3630, V3631, V3632, V3633, V3634, V3635, V3636, V3637, V3638, V3639, V3640, V3641, V3642, V3643, V3644, V3645, V3646, V3700, V3701, V3702, V3703, V3704, V3705, V3706, V3707, V3708, V3709, V3710, V3712, V3713, V3714, V3715, V3716, V3717, V3718, V3719, V3720, V3721, V3722, V3723, V3724, V3725, V3726, V3727, V3728, V3729, V3730, V3731, V3732, V3733, V3734, V3736, V3737, V3738, V3739, V3740, V3741, V3742, V3743, V3744, V3745, V3746, V3748, V3749, V3750, V3800, V3801, V3802, V3803, V3804, V3805, V3806, V3807, V3808, V3809, V3810, V3811, V3812, V3813, V3814, V3815, V3816, V3817, V3818, V3819, V3820, V3821, V3822, V3823, V3824, V3825, V3826, V3827, V3828, V3829, V3830, V3831, V3832, V3833, V3834, V3835, V3836, V3837,

V3838, V3839, V3840, V3841, V3842, V3843, V3844, V3845, V3846, V3847, V3848, V3849, V3850, V3851, V3852, V3853, V3854, V3855, V3856, V3857, V3900

## **HP**

500, 520, 540, 541

### **HP Business notebook**

6930p, 6910p, 6520s, 6510b, 6535s, 6520, 6530b, NC6400

### **HP EliteBook**

6930p

### **HP Pavilion**

dv2000, dv2000 series, dv2899ed, dv2500, dv2386ea

### **Fujitsu Siemens AMILO**

L7310

### **Fujitsu Siemens AMILO PRO**

V3000, V3405

### **Fujitsu Siemens ESPRIMO**

M9400

M9415

### **Fujitsu Siemens ESPRIMO MOBILE**

M9400, M9410, M9415

### **Fujitsu Siemens FMV BIBLO**

MG50, MG75, NB90, NX90

### **Fujitsu Siemens LIFEBOOK**

985, 990, C4120, C4235, C5110, C5130, C6330, E335, L470, S6510, S6520, S7111, S7210, S7211, S7220

## **Gateway**

3109, 6816, M255, M3418, M350A, M3707, ML3000, ML3106, ML3108, ML3109, ML3706, ML3707, MP3422, MS3422, MT3000, MT3104, MT3105, MT3107, MT3110, MT3110, MT3111, MT3112, MT3303, MT3304, MT3305, MT3410, MT3418, MT3419, MT3421, MT3422, MT3423, MT3705, MT3707, MT3708, MT3710, MT3712, MT3713, MT3715, MX310, MX3102, MX3103, MX3138, MX3139, MX3140, MX3141, MX3142, MX3143, MX3311, MX3410, MX3412, MX3414, MX3416, MX3417, MX3422, MX3558,

MX3701, MX3702, NA1, NX200, NX260, NX270, S-7200, S-7210, S-7220, S-7225, S-7235, T-1400, T-1409, T-1424, T-1600, T-1602, T-1616, T-1620, T-1621, T-1622, T-1623, T-1625, T-1628, T-1629, T-1630, T-1631, T-313, T-6000, T-6208, T-6303, T-6304, T-6305, T-6307, T-6308, T-6311, T-6313, T-6321, T-6330, T-6339, T-6340, T-6341, T-6345, T-6346, T-6801, T-6802, T-6815, T-6816, T-6817, T-6818, T-6819, T-6820, T-6821, T-6822, T-6823, T-6828, T-6836, T-6841, T-6842, T1620, T6330, W340, W350, W3501

**Gigabyte**

W451, W466, W468

**LENOVO**

L3000, N3000, T61P

**IBM THINKPAD**

Z60, Z60T, Z61T

**Lenovo 3000**

C100, G230, G400, G410, G430, G510, G530, K100, N100, N200, N201, y410

**Lenovo IDEAPAD**

Y430

**Lenovo THINKPAD**

R400, R60, R60I, R61, R61E, R61I, SL400, SL400C, SL500, T400, T61, T61I, T61P, Y410, Z60M, Z60T, Z61E, Z61T

**Lenovo THINKPAD 3000**

3000G400, 3000G410, 3000N100, 3000N200, G400, G410, N100, N200

**LG**

LW40, R400, R405, R400, R405, T1

**MSI MEGABOOK**

S420

**Lenovo ThinkPad**

T400, T61 14.1 inch widescreen

**Packard Bell EasyNote**

GN45 series, GN45

	<p><b>Sony VAIO</b> VGN-CS series, VGN-CR series, VGN-CS31S/P, VGN-FJ series, VGN-CS11S/W, VGN-CS11S/Q, VGN-CS11S/P, VGN-CR31S/P, VGN-CS21S/R</p> <p><b>Toshiba DYNABOOK</b> CX, CX925LL, CXW, P1W, P1W 160, TW</p> <p><b>Toshiba DYNABOOK SATELLITE</b> CXW, P1W</p> <p><b>Toshiba EQUIUM</b> M50, M55</p> <p><b>Toshiba SATELLITE</b> E105, L30, L310, L35, M100 series, M100, M105, M110, M115, M200, M205, M300, M305, M305D</p> <p><b>Toshiba SATELLITE PRO</b> M300, M50, S300M</p> <p><b>Toshiba TECRA</b> A5, A6, M10 series, M10, M9, R10</p>
<p>15" 1024*768 PIXELS GLOSSY XGA LCD</p>	<p><b>Acer ASPIRE</b> 1310, 1350, 1355, 1357, 1360, 1362, 1400, 1403, 1410, 1414, 1500, 1510, 1513, 1520, 1522, 1600, 1603, 1610, 1613, 1620, 1640, 1641, 1642, 1650, 1652, 1670, 1680, 1681, 1690, 20, 2001, 2002, 2003, 2200, 2203, 2310, 2313, 3000, 3002, 3003, 3004, 3020, 3100, 3200, 3500, 3502, 3503, 3610, 3612, 3613, 3614, 3680, 3690, 4150, 4151, 5000, 5002, 5020, 5620, 5672, 803</p> <p><b>Acer EMACHINES</b> M622, MX4625, W4605, W4620, W4630, W6405</p> <p><b>Acer EXTENSA</b> 2000, 2001, 2300, 2500, 2501, 2600, 3000, 3001, 3100, 3102, 4420</p> <p><b>Acer TRAVELMATE</b> 2000, 2001, 2003, 2200, 2201, 2203, 2300, 2301, 2303, 2304, 2310, 2312, 2313, 233, 2350, 2355, 2360, 2363, 240, 2410, 2412, 2413, 242, 243, 244, 25, 250, 2500, 2501, 2502, 252, 254, 270, 2700, 2702, 272, 280, 281, 283, 290, 291, 292, 3000, 3002, 3003, 3260, 4000, 4001, 4050, 4051, 4060, 4070, 4100, 4150, 4151, 4152, 420, 422, 4222, 426, 427, 430, 432, 4400, 4401, 4500, 4502, 4600, 4601, 4650, 4652, 633, 634, 6592, 661, 662, 730,</p>

732, 734, 735, 736, 737, 738, 739, 8002

**Aopen**

1535, 1547, 1550, 1556, 1848, 2681

**ASUS**

A2500, A3, A3500, A3A, A3AC, A3E, A3F, A3H, A3HF, A3V, A3VP, A6, A6000, A6000U, A6R, A6VA, A9, A9, A9RP, A9T, F3, H2800, H2800S, L3, L3000, L3500, L4000, L5831, M50, Z7100, Z91, Z94

**Compaq ARMADA**

E500, E700

**Compaq EVO**

N1000, N1005, N1010, N1015, N1020, N1050V, N110, N180, N800

**Compaq PRESARIO**

1100, 1120, 1500, 1520, 1525, 1800, 1825, 18XL, 18XL180, 18XL181, 18XL182, 18XL183, 18XL185, 20, 2100, 2101, 2102, 2103, 2104, 2105, 2106, 2107, 2108, 2109, 2110, 2111, 2112, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2123, 2124, 2125, 2126, 2127, 2128, 2129, 2130, 2131, 2132, 2133, 2134, 2135, 2136, 2137, 2138, 2139, 2140, 2141, 2142, 2143, 2144, 2145, 2146, 2147, 2148, 2149, 2150, 2151, 2152, 2153, 2154, 2155, 2156, 2157, 2158, 2161, 2162, 2163, 2164, 2170, 2172, 2173, 2175, 2178, 2180, 2182, 2190, 2199, 2200, 2201, 2203, 2204, 2205, 2208, 2209, 2210, 2218, 2223, 2226, 2227, 2231, 2232, 2236, 2313, 2324, 2500, 2504, 2505, 2509, 2510, 2514, 2515, 2519, 2520, 2524, 2525, 2528, 2529, 2530, 2533, 2535, 2540, 2542, 2543, 2544, 2545, 2548, 2550, 2554, 2555, 2558, 2565, 2568, 2570, 2573, 2580, 2581, 2585, 2591, 2594, 2596, 2597, 2598, 2599, 2700, 2701, 271, 2710, 2711, 2712, 2715, 2716, 2720, 2800, 4125, 900, 906, 910, 916, 920, B1000, B1010, B1011, B1013, B1014, B1015, B2000, B3300, B3800, B3811, M2000, M2001, M2002, M2003, M2004, M2005, M2006, M2007, M2008, M2009, M2010, M2011, M2012, M2013, M2014, M2015, M2016, M2017, M2018, M2019, M2020, M2021, M2022, M2023, M2024, M2025, M2026, M2027, M2028, M2029, M2030, M2031, M2032, M2033, M2034, M2035, M2036, M2037, M2038, M2039, M2040, M2041, M2042, M2043, M2044, M2045, M2046, M2047, M2048, M2049, M2050, M2051, M2052, M2053, M2054, M2055, M2056, M2057, M2058, M2059, M2060, M2061, M2062, M2065, M2070, M2075, M2099, M2100, M2101, M2105, M2108, M2113, M2125, M2128, M2130, M2131, M2140, M2145, M2150, M2155, M2175, M2200, M2201, M2202, M2203, M2205, M2206, M2207, M2208, M2209, M2210, M2211, M2212, M2213, M2214, M2215, M2216, M2217, M2218, M2219, M2220, M2221, M2222, M2223, M2224, M2225, M2226, M2227, M2228, M2229, M2230, M2231, M2232, M2233, M2234,



M2235, M2236, M2237, M2238, M2239, M2240, M2241, M2242, M2243, M2244, M2245, M2246, M2247, M2248, M2249, M2250, M2251, M2252, M2253, M2254, M2255, M2256, M2257, M2258, M2259, M2260, M2261, M2262, M2300, M2301, M2302, M2305, M2308, M2310, M2316, M2318, M2350, M2355, M2356, M2357, M2358, M2370, M2397, M2400, M2500, R3000, R3001, R3002, R3003, R3004, R3019, R3030, R3038, R3050, R3055, R3060, R3065, R3070, R3100, R3103, R3120, R3140, R3150, R3160, R3190, R3200, R3201, R3202, R3203, R3204, R3205, R3207, R3210, R3211, R3215, R3220, R3249, R3300, R3306, R3310, R3320, R3340, R3358, R3360, R3370, R3396, R3399, R3400, R3405, R3415, R3422, R3425, R3430, R3440, R3460, R3470, R4000, R4001, R4002, R4003, R4005, R4006, R4009, R4010, R4012, R4015, R4016, R4017, R4024, R4025, R4026, R4028, R4029, R4030, R4031, R4035, R4060, R4065, R4075, R4100, R4114, R4115, R4125, R4126, R4127, R4130, R4145, R4146, R4150, R4155, R4157, R4200, R4225, R4300, V1000, V1001, V1002, V1003, V1004, V1005, V1006, V1007, V1008, V1009, V1010, V1011, V1012, V1013, V1014, V1015, V1016, V1017, V1018, V1019, V1020, V1021, V1022, V1023, V1024, V1025, V1026, V1027, V1028, V1030, V1031, V1032, V1033, V1034, V1035, V1036, V1037, V1038, V1039, V1040, V1041, V1042, V1043, V1044, V1045, V1046, V1047, V1048, V1049, V1050, V1051, V1052, V1053, V1054, V1055, V1056, V1057, V1058, V1059, V1060, V1061, V1062, V1065, V1066, V1067, V1068, V1069, V1070, V1071, V1072, V1073, V1074, V1075, V1100, V1101, V1102, V1103, V1104, V1105, V1106, V1107, V1108, V1109, V1110, V1111, V1112, V1113, V1114, V1115, V1116, V1117, V1118, V1119, V1120, V1121, V1122, V1123, V1124, V1125, V1126, V1127, V1129, V1130, V1131, V1132, V1133, V1134, ZE4535, ZE4900, ZE4901, ZE4902, ZE4903, ZE4904, ZE4905, ZE4906, ZE4907, ZE4908, ZE4910, ZE4911, ZE4912, ZE4913, ZE4914, ZE4915, ZE4916, ZE4917, ZE4918, ZE4919, ZE4920, ZE4921, ZE4922, ZE4923, ZE4925, ZE4926, ZE4927, ZE4928, ZE4929, ZE4930, ZE4931, ZE4932, ZE4933, ZE4934, ZE4935, ZE4936, ZE4937, ZE4938, ZE4939, ZE4940, ZE4941, ZE4942, ZE4943, ZE4944, ZE4945, ZE4946, ZE4947, ZE4948, ZE4949, ZE4950, ZE4951, ZE4952, ZE4953, ZE4954, ZE4955, ZE4956, ZE4957, ZE4958, ZE4960, ZE4961, ZE4962, ZE4965, ZE4995

**Dell INSPIRON**

1000, 1100, 1150, 1200, 2200, 2500, 2600, 2650, 5000, 5100, 5105, 510M, 5150, 5160, 7000, 7500, 8000, 8100, 8200

**Dell LATITUDE**

100L, 110L, C800, C840, D500, D505, D510, D520, D530, D530N, D600, D610, L110, V505

**Dell SMARTSTEP**

200N

**Fujitsu Siemens**

C1120, D7830

**Fujitsu Siemens AMILO**

7400, A-1400, A-7600, A-7640, A-7640W, A-7645, A7600, A7620, A7640, A7640W, A7645, A8620, D-7820, D-7830, D-CY23, D-CY23, D5100, D5500, D6820, D7100, D7500, D7800, D7820, D7830, D7850, D8800, D8820, D8830, K-7610, K7610, K7610W, L-6820, L-6825, L-7300, L6820, L6825, L7300, M-7400, M-7405, M-7440, M7300, M7400, M7405, M7424, M7425, M7440, M7440G, M7800

**Fujitsu Siemens AMILO PRO**

V1000, V2000, V2010, V2020, V2030, V2030D, V2040, V2080, V7010, V8010, V8010D

**Fujitsu Siemens FMV-BIBLO**

NB40M, NB40N, NB40S, NB50E, NB50M, NB55, NB90

**Fujitsu Siemens LIFEBOOK**

A3040, C1020, C1110, C1110D, C1211D, C1320, C1410, C2000, C2010, C2110, C2111, C2210, C2220, C2310, C2320, C2330, C2340, C6611, C6631, C6651, C7631, C7651, C7661, C8220, E2010, E8000, E8010, E8020, E8020D, E8110, E8310, E8410, L2010, L2020, N3010

**Fujitsu Siemens LIFEBOOK X**

X7530, X7550, X7560, X7570, X7595

**Gateway**

400, 4010, 4030, 4046, 450, 4520, 4525, 4526, 4540, 4541, 4542, 4543, 4546, 4547, 4548, 4550, 600, 7510, M305, M320, M325, M350, M360, M405, M460, M465, M520, MX-4610, MX325, MX4000, NX-500, NX-550, S-7310, S-7500, S-7510

**Gateway SOLO**

1400, 1450, 9150, 9300, 9500, 9550

**HP**

6870S, NX6100, NX6115, NX6120, NX6125, NX6310, NX6320, NX6325, NX9000, NX9005, NX9008, NX9020, NX9030, NX9040, NX9100, NX9105,

NX9110

**HP**

XE4400, XE4500

**HP BUSINESS NOTEBOOK**

N1050V, N6120, NC6100, NC6110, NC6120, NC6140, NC6315, NC6320, NC8000, NC8000P, NX5000, NX6100, NX6110, NX6110DF, NX6115, NX6120, NX6125, NX6130, NX6310, NX6315, NX6320, NX6325, NX6330, NX8220, NX9000, NX9005, NX9008, NX9010, NX9020, NX9030, NX9040, NX9100, NX9105, NX9110

**HP MOBILE WORKSTATION**

NW8000

**HP OMNIBOOK**

6000, 6100, XE3, XE3B, XE3C, XE3G, XE4500, XT1000, XT1500

**HP PAVILION**

N5000, N5100, N5125, N5130, N5135, N5140, N5150, N5170, N5190, N5195, N5200, N5240, N5241, N5270, N5271, N5290, N5295, N5300, N5310, N5311, N5340, N5341, N5350, N5351, N5371, N5381, N5390, N5400, N5401, N5402, N5412, N5415, N5420, N5421, N5422, N5425, N5430, N5435, N5440, N5441, N5442, N5444, N5445, N5450, N5451, N5452, N5454, N5455, N5461, N5462, N5470, N5472, N5474, N5475, N5481, N5482, N5484, N5490, N5491, N5500, N5511, N5584, NX9030, XF200, XF255, XF300, XF328, XH100, XH136, XH156, XH176, XH300, XH355, XH365, XH395, XH400, XH455, XH485, XH500, XH535, XH545, XH555, XH575, XH600, XH675, XT100, XT115, XT125, XT128, XT1500, XT155, XT178, XT183, XT188, XT200, XT236, XT276, XT300, XT345, XT375, XT395, XT4316, XT4345, XT500, XT512, XT5300, XT5335, XT5366, XT5377, XT545, XT5477, XT555, XT565, XT575, XT585, XT595, XZ100, XZ148, XZ168, XZ185, XZ200, XZ275, XZ295, XZ300, XZ335, XZ355, ZD5570, ZE1100, ZE1200, ZE1230, ZE1250, ZE2000, ZE2000T, ZE2000Z, ZE2001, ZE2002, ZE2003, ZE2004, ZE2005, ZE2006, ZE2007, ZE2008, ZE2009, ZE2010, ZE2011, ZE2012, ZE2013, ZE2015, ZE2040, ZE2070, ZE2100, ZE2113, ZE2114, ZE2115, ZE2117, ZE2200, ZE2300, ZE2315, ZE4000, ZE4100, ZE4101, ZE4102, ZE4103, ZE4111, ZE4115, ZE4120, ZE4123, ZE4125, ZE4130, ZE4133, ZE4140, ZE4145, ZE4200, ZE4220, ZE4228, ZE4231, ZE4232, ZE4236, ZE4239, ZE4240, ZE4251, ZE4261, ZE4268, ZE4271, ZE4284, ZE4288, ZE4292, ZE4298, ZE4300, ZE4306, ZE4315, ZE4318, ZE4325, ZE4335, ZE4345, ZE4365, ZE4400, ZE4402, ZE4407, ZE4410, ZE4414, ZE4416, ZE4417, ZE4420, ZE4427, ZE4430, ZE4455, ZE4500, ZE4510, ZE4512, ZE4516, ZE4520, ZE4522, ZE4523, ZE4525,

ZE4530, ZE4540, ZE4547, ZE455, ZE4550, ZE4560, ZE4600, ZE4601, ZE4603, ZE4604, ZE4605, ZE4610, ZE4612, ZE4614, ZE4615, ZE4630, ZE4631, ZE468, ZE4700, ZE4710, ZE4715, ZE4717, ZE4718, ZE4725, ZE4800, ZE4801, ZE4805, ZE4815, ZE4819, ZE4820, ZE4821, ZE4900, ZE4901, ZE4903, ZE4904, ZE4906, ZE4908, ZE4910, ZE4911, ZE4914, ZE4919, ZE4930, ZE4933, ZE4935, ZE4941, ZE4942, ZE4944, ZE4945, ZE5000, ZE5100, ZE5155, ZE5170, ZE5185, ZE5200, ZE5232, ZE5238, ZE5240, ZE5258, ZE5262, ZE5270, ZE5279, ZE5300, ZE5345, ZE5357, ZE5375, ZE5400, ZE5447, ZE5451, ZE5457, ZE5468, ZE5470, ZE5475, ZE5490, ZE5500, ZE5527, ZE5537, ZE5570, ZE5580, ZE5590, ZE5600, ZE5602, ZE5603, ZE5604, ZE5605, ZE5607, ZE5610, ZE5615, ZE5617, ZE5620, ZE5631, ZE5634, ZE5650, ZE5700, ZE5701, ZE5715, ZE5730, ZE5740, ZE5749, ZT1000, ZT1100, ZT1114, ZT1120, ZT1121, ZT1122, ZT1125, ZT1130, ZT1131, ZT1132, ZT1135, ZT1141, ZT1142, ZT1145, ZT1150, ZT1151, ZT1152, ZT1155, ZT1161, ZT1162, ZT1170, ZT1171, ZT1172, ZT1175, ZT1182, ZT1185, ZT1190, ZT1192, ZT1195, ZT1200, ZT1201, ZT1210, ZT1211, ZT1213, ZT1230, ZT1231, ZT1233, ZT1235, ZT1243, ZT1250, ZT1260, ZT1270, ZT1271, ZT1290, ZV5000, ZV5001, ZV5002, ZV5005, ZV5009, ZV5010, ZV5014, ZV5016, ZV5017, ZV5020, ZV5021, ZV5027, ZV5028, ZV5029, ZV5030, ZV5034, ZV5037, ZV5040, ZV5100, ZV5101, ZV5102, ZV5103, ZV5105, ZV5114, ZV5118, ZV5120, ZV5122, ZV5129, ZV5138, ZV5142, ZV5149, ZV5150, ZV5151, ZV5157, ZV5160, ZV5167, ZV5176, ZV5177, ZV5179, ZV5183, ZV5200, ZV5300, ZV5301, ZV5303, ZV5316, ZV5322, ZV5324, ZV5360, ZV5367, ZV5370, ZV5380, ZV5386, ZV5400, ZV5404, ZV5405, ZV5410, ZV5415, ZV5420, ZV5430, ZV5434, ZV5440, ZV5445, ZV5450, ZV5454, ZV5455, ZV5456, ZV5460, ZV5466, ZV5470, ZV5476, ZV6000, ZV6004, ZX5000, ZX5001, ZX5002, ZX5010, ZX5040, ZX5065, ZX5070, ZX5078, ZX5100, ZX5180, ZX5190, ZX5200, ZX5275, ZX5280, ZX5295

**IBM THINKPAD**

172X, 390X, A20M, A21E, A22M, A30, A31, G40, G41, R40, R40E, R50, R50E, R50P, R51, R51E, R52, R60, R60E, T40, T40P, T41, T41P, T42, T42P, T43, T43P, T60, T60P

**Lenovo 3000**

C100, C200, N100

**Lenovo THINKPAD**

E290, R60, R60E, R60I, R61, R61E, R61I, T60, T60P, T61I

**LG**

K1, LE50, LS50, LS50A, LS75, NZ2

**LG ELECTRONICS**

K1, LE50, LS50

**LG EXPRESS**

V1

**Packard Bell EASYNOTE**

5301, C3300, E3245, E4810, E6315, G1320, H5, K5285, M5, M5-300DR, QUA-NR1

**Packard Bell I POWER**

5000

**Samsung**

NP-X20, NP-X25, R45, R65, V25, X15, X20, X25

**Sony VAIO**

PCG-715M, PCG-9P6LE, PCG-F290, PCG-F309, PCG-F390, PCG-F480, PCG-F490, PCG-F580, PCG-F580K, PCG-F590, PCG-F590K, PCG-F660, PCG-F660T, PCG-F680, PCG-F680K, PCG-F709, PCG-F808K, PCG-FR105, PCG-FR215E, PCG-FR215H, PCG-FR215M, PCG-FR215S, PCG-FR285E, PCG-FR285M, PCG-FR295MP, PCG-FR315B, PCG-FR315M, PCG-FR315S, PCG-FR395EP, PCG-FR415B, PCG-FR415M, PCG-FR415S, PCG-FR495EP, PCG-FR825P, PCG-FRV23, PCG-FRV25, PCG-FRV26, PCG-FRV27, PCG-FRV28, PCG-FRV295, PCG-FRV31, PCG-FRV33, PCG-FRV34, PCG-FRV35, PCG-FRV37, PCG-FX108K, PCG-FX150, PCG-FX170, PCG-FX200, PCG-FX205K, PCG-FX215, PCG-FX220, PCG-FX220K, PCG-FX250, PCG-FX250K, PCG-FX302K, PCG-FX370, PCG-FX370K, PCG-FX370P, PCG-FX390, PCG-FX390K, PCG-FX390P, PCG-FX404, PCG-FX405, PCG-FX505, PCG-FX604, PCG-FX605, PCG-FX804, PCG-FX849, PCG-FXA32, PCG-FXA33, PCG-FXA36, PCG-FXA47, PCG-FXA48, PCG-FXA49, PCG-GR150K, PCG-GR150P, PCG-GR170, PCG-GR215MK, PCG-GR215MP, PCG-GR2615S, PCG-GR270, PCG-GR270K, PCG-GR270P, PCG-GR300, PCG-GR300K, PCG-GR315MP, PCG-GR370, PCG-GR370K, PCG-GR370P, PCG-GRS100, PCG-GRS100K, PCG-GRS150, PCG-GRS170, PCG-GRS175, PCG-GRS300, PCG-GRS515M, PCG-GRS515SP, PCG-GRS615SK, PCG-GRS615SP, PCG-GRS700P, PCG-GRT100, PCG-GRT100K, PCG-GRT100P, PCG-GRT160, PCG-GRT240G, PCG-GRT250, PCG-GRT250K, PCG-GRT250P, PCG-GRT25F, PCG-GRT270, PCG-GRT270G, PCG-GRT270P, PCG-GRT35F, PCG-GRT715E, PCG-GRT715M, PCG-GRT785E, PCG-GRT795MP, PCG-GRT815E, PCG-GRT815M, PCG-GRT895MP, PCG-GRT915M, PCG-GRT995MP, PCG-GRX315MK, PCG-GRX315MP, PCG-GRX415MK, PCG-GRX415MP, PCG-GRX500, PCG-GRX501, PCG-GRX510, PCG-GRX520, PCG-GRX530, PCG-GRX550, PCG-GRX616, PCG-GRZ515G, PCG-GRZ530, PCG-GRZ600, PCG-GRZ610, PCG-GRZ615G, PCG-GRZ615M, PCG-GRZ615S, PCG-

GRZ630, PCG-GRZ660, PCG-K10, PCG-K115B, PCG-K115M, PCG-K115S, PCG-K115Z, PCG-K12FP, PCG-K12P, PCG-K13, PCG-K13F, PCG-K13Q, PCG-K14, PCG-K15, PCG-K15F, PCG-K17, PCG-K195BP, PCG-K195HP, PCG-K20P, PCG-K215B, PCG-K295HP, PCG-NV100, PCG-NV109M, PCG-NV170, PCG-NV170P, PCG-NV190, PCG-NV190P, PCG-NV200, PCG-NV209, PCG-NV309, PCG-NVR23, VGN-81B/B, VGN-A115B, VGN-A115S, VGN-A130, VGN-A130B, VGN-A130P, VGN-A195EP, VGN-A195HP, VGN-A230, VGN-A230B, VGN-A230P, VGN-BX195, VGN-BX195EP, VGN-BX195SP, VGN-BX195SPF, VGN-BX195VP, VGN-BX195VPF, VGN-BX195XP, VGN-BX195XPF, VGN-BX295SP, VGN-BX295VP, VGN-E50B, VGN-E51B, VGN-E70B, VGN-E71B, VGN-E72B, VGN-E81B, VGN-E91B, VGN-E92B, VGN-FS215E, VGN-FS295VP, VGN-K30, VGN-K30B, VGN-K50B, VGN-K70B

### **Toshiba**

S2430

### **Toshiba DYNABOOK**

1800, 1850, 1860, 1870, 4360, 4380, 4600, 6000, 8200-151, A1/10, A1/570, A1/X10, A10, A11, A2/580, AW4, AX, AX/2525, AX/2528, AX/3527, AX/353, AX/530, AX/550, AX/630, AX/650, DB70P/5, E10/1, E10/2, E10/370, E10/375, E5/511, E6/515, E7/518, E8, E8-520, E8/420, E8/520, EX/2513, EX/2515, EX/522, EX1/522, EX1/524, G3/510, G4/510, J10, J11, J12, J30, J31, J32, J40, J50, J60, J61, J62, J63, J70, M10, P10, P5/522, PATX3514, PX/410, T10, T11, T12, T20, T5/512, T6/518, TX-550, TX/2513, TX/2515, TX/2517, TX/3514, TX/3516, TX/430, TX/450, TX/470, TX/550, TX/650, V7/513, V7/516, V8/513

### **Toshiba DYNABOOK QOSMIO**

E10

### **Toshiba DYNABOOK SATELLITE**

1800, 1850, 1860, 1870, 4000, 4360, 4380, 6000, A10, A11, AW4, J10, J11 240C, J12, J30, J31 150L, J32, J40, J50, J60, J61, J62, J63, J70, M10, P10, T10, T11, T12, T20, T20 140C, T5

### **Toshiba EQUIUM**

100, A60, A80, L10, L100, L20, M50

### **Toshiba QOSMIO**

E10, E15

### **Toshiba SATELLITE**

1130, 1135, 1400, 1405, 1410, 1415, 1800, 1805, 1810, 1815, 1900, 1905, 2400, 2405, 2410, 2415, 2416, 2430, 2435, 2450, 2455, 2800, 2800X,

2805, 2810, 2815, 5000, 5005, 5100, 5200, 6000, A10, A15, A20, A25, A30, A35, A40, A45, A50, A55, A60, A65, A80, A85, AS50, L10, L100, L15, L20, L25, M30X, M35X, PSL10A, PSL20E, R55, S2430, S2450, SA10, SA30, SA50

**Toshiba SATELLITE PRO**

1120, 2100, 4280, 4300, 4360, 4600, 6000, 6100, A10, A30, A40, A60, L10, L100, L20, L25, L2V, M10, M15, P40

**Toshiba TECRA**

A1, A2, A3, A3X, L2, S1, S2, S3, S4

**Unwill**

N251S6, N351S2, N351S4

15.4"  
1280\*800  
PIXELS  
GLOSSY  
WXGA LCD  
(WITH OR  
WITHOUT  
DELL  
INVERTER)

**Acer ASPIRE**

1352, 1360, 1362, 1363, 1400, 1410, 1412, 1414, 1500, 1520, 1522, 1524, 1600, 1630, 1632, 1640, 1641, 1642, 1644, 1650, 1654, 1660, 1661, 1662, 1670, 1672, 1673, 1680, 1681, 1682, 1683, 1684, 1685, 1689, 1690, 1691, 1692, 1694, 2000, 2001, 2002, 2003, 2010, 2012, 2020, 2023, 2025, 2110, 3000, 3002, 3003, 3004, 3005, 3020, 3022, 3023, 3025, 3030, 3040, 3100, 3102, 3103, 3104, 3500, 3502, 3503, 3510, 3610, 3613, 3614, 3618, 3630, 3633, 3634, 3650, 3651, 3660, 3680, 3690, 3692, 3693, 3694, 4000, 4001, 4002, 4010, 4011, 4021, 4060, 4061, 4062, 4064, 4070, 4072, 4074, 4100, 4101, 4102, 4150, 4200, 4201, 4220, 4222, 4230, 4400, 4402, 4500, 4600, 4601, 5000, 5002, 5003, 5004, 5010, 5020, 5022, 5024, 5040, 5043, 5044, 5100, 5101, 5102, 5103, 5110, 5112, 5220, 5230, 5310, 5315, 5320, 5400, 5510, 5514, 5515, 5520, 5530, 5540, 5570, 5579, 5600, 5601, 5602, 5610, 5611, 5612, 5613, 5614, 5620, 5621, 5622, 5630, 5632, 5633, 5634, 5635, 5650, 5652, 5670, 5672, 5673, 5674, 5675, 5680, 5683, 5684, 5685, 5710, 5715, 5720, 5730, 5910, 5920, 5930, 5970, 6002, 6124, 6173, 6185, 6254, 6296, 6298, 6368, 6371, 6400, 6401, 6436, 6444, 6655, 6670, 6679, 6803, 6806, 6891, 6895, 6943, 9100, 9110, 9120, AS5930, BL51, ICL50, ZL5

**Acer EMACHINES**

E510, E520, E620, E720, M2105, M2350, M2352, M2356, M5105, M5116, M5124, M5124, M5305, M5307, M5309, M5310, M5312, M5313, M5405, M5410, M5412, M5414, M6410, M6805, M6807, M6809, M6810, M6811, M8611, MX4624, MX4625, W4605, W4620, W4630

**Acer EXTENSA**

2200, 3000, 3001, 3002, 3103, 4100, 4102, 5010, 5120, 5200, 5210, 5220, 5230, 5410, 5420, 5510, 5610, 5620, 5630, 6600, 6700

**Acer FERRARI**

4000, 4002, 4003, 4005, 5000, 5005

**Acer TRAVELMATE**

1360, 1362, 1680, 1690, 2100, 2200, 2201, 2203, 2300, 2301, 2303, 2304, 2310, 2312, 2313, 2350, 2400, 2410, 2413, 2430, 2434, 2450, 2451, 2490, 2492, 2493, 2494, 2600, 2700, 2701, 2702, 4000, 4001, 4002, 4010, 4011, 4020, 4021, 4060, 4061, 4062, 4064, 4070, 4072, 4074, 4100, 4101, 4102, 4150, 4151, 4200, 4202, 4203, 4210, 4220, 4222, 4223, 4230, 4233, 4234, 4235, 4260, 4270, 4272, 4280, 4282, 4283, 4400, 4402, 4404, 4500, 4501, 4502, 4600, 4601, 4670, 4672, 4720, 5320, 5330, 5520, 5530, 5720, 5730, 6410, 6592, 6593, 8100, 8103, 8200, 8204

**Aopen**

2000,3000

**Apple POWERBOOK**

A1001, A1025, M5884, M8407

**ASUS**

9200G, A4, A4000, A5EB, A5EC, A5L, A6, A6000, A6000J, A6000JA, A6000KM, A6000KT, A6727, A6AV, A6B00U, A6F, A6G, A6GA, A6J, A6JA, A6JB, A6JC, A6JM, A6KM, A6KT, A6L, A6M, A6NE, A6P, A6Q, A6R, A6RT, A6RTC, A6T, A6TC, A6U, A6V, A6VC, A6VM, A6VN, B50A, EEE PC A6J, F3, F3, F3E, F3F, F3FG, F3JA, F3JC, F3JM, F3JP, F3JR, F3JV, F3KA, F3S, F3SA, F3SC, F3T, F5, F5C, F5GL, F5M, F5N, F5R, F5RL, F5SL, F5SR, F5V, F5Z, G1, G15, G1S, G50V, M50, M50SA, M50SV, M50VM, M50VN, M51, M51N, M51S, M51SR, M6, M6000, M6000N, M6700N, M6707R, M6742NE, M6A, M6B, M6N, M6V, M7A, M7M, M7V, N50VC, N50VG, PRO 31JC, PRO 50, PROA120-190, S96, S96, S960, S960S, S96F, S96J, V1, V1J, V1JP, V1S, V1V, W3000, X50, X50AD, X50C, X50G, X50GL, X50M, X50N, X50R, X50RL, X50SL, X50V, X50VL, X50XR, X50Z, X51, X51R, X51RL, X53, X53S, X55, X55SR, X55SV, X57, X57SA, X57SR, X57SV, X57VC, X57VM, X57VN, X58, X58C, X59, X59GL, X59SL, X59SR, X5AV, X5AVC, X5AVN, X5L, Z53, Z53J, Z53JC, Z70VA, Z71, Z7100, Z7100A, Z7100VP, Z9100, Z92, Z9200, Z93, Z96

**ASUS PRO**

31P

**Benq JOYBOOK**

R53, R55, R55VEG

**Clevo**

D450T, M66SE, M66SU



**Compal**

FL90, FL91, FL92

**Compaq**

NW8440

**Compaq**

NX9110

**Compaq MOBILE WORKSTATION**

NW8440

**Compaq PAVILION**

DV5036, DV5037, DV5040, DV5041, DV5046, DV5047, DV5051, DV5052, DV5053, DV5054, DV5055, DV5057, DV5058, DV5059, DV5061, DV5062, DV5063, DV5074, DV5075, DV5077, DV5078, DV5084, DV5088, DV5091, DV5092, DV5093, DV5094, DV5095, DV5096, DV5097, DV5098, DV5099, DV5100, DV5102, DV5104, DV5105, DV5106, DV5107, DV5108, DV5109, DV5110, DV5111, DV5112, DV5113, DV5115, DV5116, DV5117, DV5118, DV5120, DV5121, DV5122, DV5123, DV5124, DV5125, DV5126, DV5127, DV5128, DV5129, DV5130, DV5131, DV5132, DV5133, DV5135, DV5137, DV5139, DV5140, DV5142, DV5143, DV5144, DV5145, DV5147, DV5148, DV5149, DV5150, DV5156, DV5157, DV5158, DV5159, DV5160, DV5161, DV5162, DV5163, DV5164, DV5165, DV5166, DV5167, DV5170, DV5173, DV5175, DV5176, DV5177, DV5178, DV5179, DV5180, DV5184, DV5188, DV5190, DV5191, DV5192, DV5193, DV5194, DV5195, DV5196, DV5197, DV5198, DV5199, DV5200, DV5201, DV5202, DV5203, DV5204, DV5205, DV5206, DV5207, DV5208, DV5209, DV5210, DV5211, DV5212, DV5213, DV5215, DV5216, DV5217, DV5218, DV5219, DV5220, DV5221, DV5222, DV5223, DV5224, DV5225, DV5226, DV5227, DV5228, DV5229, DV5230, DV5231, DV5232, DV5233, DV5234, DV5235, DV5236, DV5237, DV5238, DV5239, DV5240, DV5241, DV5242, DV5243, DV5244, DV5245, DV5246, DV5247, DV5248, DV5249, DV5250, DV5251, DV5252, DV5255, DV5261, DV5264, DV5266, DV5267, DV5269, DV5270, DV5271, DV5272, DV5273, DV5274, DV5275, DV5276, DV5277, DV5278, DV5279, DV5280, DV5281, DV5282, DV5283, DV5284, DV5285, DV5286, DV5287, DV5288, DV5289, DV5292, DV5293, DV5294, DV5295, DV5296, DV5298, DV5299, DV5T, DV5T1100, DV5TSE, DV5Z, DV5Z-1000, DV6000, DV6001, DV6010, DV6022, DV6025, DV6040, DV6045, DV6058, DV6100, DV6101, DV6102, DV6103, DV6104, DV6105, DV6106, DV6107, DV6108, DV6109, DV6110, DV6111, DV6112, DV6113, DV6114, DV6115, DV6116, DV6119, DV6120, DV6125, DV6128, DV6129, DV6130, DV6131, DV6135, DV6139, DV6140, DV6149, DV6150, DV6154, DV6165, DV6171, DV6174, DV6184, DV6195,

DV6197, DV6200, DV6205, DV6225, DV6226, DV6227, DV6235, DV6236, DV6243, DV6244, DV6245, DV6247, DV6253, DV6255, DV6256, DV6263, DV6265, DV6266, DV6267, DV6275, DV6300, DV6304, DV6305, DV6306, DV6307, DV6308, DV6315, DV6317, DV6324, DV6325, DV6326, DV6327, DV6335

**Compaq PRESARIO**

1000, 1030, 6700, C300, C301, C302, C303, C304, C305, C306, C307, C308, C309, C310, C311, C312, C313, C315, C318, C350, C351, C352, C353, C399, C500, C501, C502, C503, C504, C506, C507, C508, C509, C518, C540, C542, C551, C552, C554, C555, C556, C557, C559, C560, C561, C563, C568, C571, C573, C576, C581, C582, C700, C700T, C701, C702, C703, C704, C705, C706, C707, C708, C709, C710, C712, C713, C714, C715, C716, C717, C720, C725, C727, C729, C730, C731, C732, C737, C742, C750, C751, C752, C754, C756, C757, C758, C759, C760, C770, CQ50, CQ50-101, CQ50-102, CQ50-103, CQ50-111, CQ50-115, CQ50-116, CQ50-209, CQ50Z, CQ50Z-100, DV1640, F500, F5000, F502, F503, F505, F506, F551, F552, F553, F555, F557, F558, F560, F562, F564, F565, F566, F572, F576, F577, F579, F700, F705, F706, F710, F712, F715, F722, F725, F729, F730, F731, F732, F739, F750, F752, F754, F755, F756, F759, F761, F762, F763, F764, F765, F767, F768, F769, M-6867, R3000, R3001, R3002, R3003, R3004, R3019, R3030, R3038, R3050, R3055, R3060, R3065, R3070, R3100, R3103, R3120, R3140, R3150, R3160, R3190, R3200, R3201, R3202, R3203, R3204, R3205, R3210, R3215, R3220, R3230, R3240, R3245, R3247, R3255, R3260, R3275, R3290, R3300, R3306, R3310, R3320, R3340, R3360, R3370, R3396, R3399, R3400, R3405, R3410, R3415, R3425, R3430, R3440, R3460, R3470, R4000, R4001, R4002, R4003, R4005, R4009, R4010, R4012, R4015, R4016, R4017, R4024, R4025, R4026, R4028, R4029, R4030, R4031, R4035, R4060, R4065, R4075, R4100, R4115, R4125, R4127, R4200, R4225, R4300, V015, V2025, V4000, V4001, V4002, V4003, V4004, V4005, V4015, V4020, V4035, V4040, V4050, V4055, V4058, V4060, V4075, V4100, V4101, V4102, V4103, V4104, V4105, V4106, V4107, V4108, V4109, V4110, V4111, V4112, V4113, V4114, V4115, V4116, V4117, V4118, V4119, V4120, V4121, V4122, V4125, V4130, V4133, V4135, V4144, V4145, V4146, V4147, V4160, V4200, V4203, 4205, 4215, 4220, 4229, 4240, 4245, V4300, V4310, V4325, 4332, 4400, 5000, V5005, V5015, V5020, V5025, V5030, V5088, V5099, V5100, V5101, V5102, V5105, V5115, V5119, V5120, V5150, V5155, V5160, V5200, V5201, V5202, V5203, V5204, V5205, V5206, V5207, V5208, V5209, V5210, V5211, V5212, V5213, V5214, V5215, V5216, V5217, V5218, V5219, V5220, V5221, V5222, V5223, V5224, V5225, 5226, 5227, 5228, 5229, V5230, V5231, V5232, V5233, V5234, V5235, V5236, V5237, V5238, V5239, V5240, V5241, V5242, V5243, V5244, V5245, V5246, V5247, V5300, V5303, V5304, V5305,

V5306, V5307, V5308, V5310, V5315, V6000, V6001, V6002, V6003, V6012, V6014, V6016, V602, V6024, V6025, V6030, V6048, V6057, V6065, V6066, V6100, V6101, V6102, V6103, V6104, V6105, V6106, V6107, V6108, V6109, V6110, V6111, V6113, V6114, V6115, V6117, V6120, V6130, V6131, V6133, V6137, V6139, V6141, V6143, V6155, V6171, V6182, V6200, V6201, V6202, V6203, V6204, V6205, V6206, V6207, V6208, V6209, V6210, V6212, V6213, V6214, V6215, V6216, V6217, V6218, V6219, V6220, V6221, V6225, V6230, V6239, V6254, V6261, V6300, V6304, V6305, V6306, V6308, V6309, V6310, V6311, V6312, V6313, V6314, V6315, V6316, V6318, V6319, V6320, V6321, V6322, V6335, V6336, V6337, V6345, V6346, V6355, V6400, V6401, V6402, V6403, V6404, V6405, V6406, V6407, V6408, V6409, V6410, V6411, V6415, V6420, V6425, V6429, V6430, V6435, V6444, V6450, V6500, V6501, V6502, V6503, V6504, V6505, V6506, V6507, V6508, V6509, V6510, V6511, V6512, V6513, V6514, V6515, V6516, V6530, V6554, V6560, V6570, V6590, V6594, V6595, V6599, V6600, V6615, V6620, V6642, V6700, V6800, V6801, V6802, V6803, V6804, V6805, V6806, V6807, V6810, V6850, VV6317, X1000, X1005, X1006, X1007, X1010, X1011, X1012, X1015, X1018, X1020, X1026, X1027, X1028, X1031, X1032, X1033, X1034, X1035, X1036, X1037, X1038, X1040, X1041, X1042, X1043, X1044, X1051, X1052, X1053, X1054, X1057, X1058, X1060, X1061, X1062, X1067, X1068, X1072, X1075, X1076, X1077, X1078, X1079, X1080, X1087, X1088, X1089, X1090, X1092, X1093, X1096, X1098, X1099, X1100, X1155, X1200, X1300, X1400, X1434

**Dell DIMENSION**

6000

**Dell INSPIRON**

1300, 1501, 150L, 1510, 1520, 1521, 1525, 1526, 1535, 6000, 6400, 8130, 8500, 8600, 9100, B130, B131, C6066, D130, D1501, E1501, E1505, PP20L, PP21I, PP21L, PP22L, PP23LA, PP29L, XPS

**Dell LATITUDE**

131L, 6000, D531, D800, D810, D820, D830, E5500, E6500

**Dell PRECISION**

1000, 1500, M4400, M65, M70

**Dell STUDIO**

15, 1535, 1536

**Dell VOSTRO**

1000, 1500, 1501, 1510, 500

**Dell XPS**

1530-147B, 1530B-8107, M1530

**Fujitsu Siemens AMILO**

A-1630, A-1640, A-1645, A-1645G, A-1650, A-1650G, A-1655, A-1655G, A-1667, A-3110, A1630, A1640, A1645, A1645G, A1650, A1650G, A1655, A1655G, A1665, A1667, A1667G, A24400, A3110, D-1840, D-1840W, D-1845, D1840, D1840W, D1845, D7830, L-1300, L-1310, L-1310G, L-7310GW, L-7320GW, L1300, L1310, L1310G, L1718, L1718G, L310G-S, L7300, L7300G, L7300T, L7301S, L7310, L7310, L7310G, L7310GW, L7310W, L7320, L7320G, L7320GW, LA-1703, LA1703, LA1703, LI-1705, LI-1718, LI-1720, LI1705, LI1718, LI1718G, LI1720, LI2727, LI2732, LI2735, M-1420, M-1425, M-1437G, M-1451G, M1405, M1420, M1424, M1425, M1425G, M1437, M1437G, M1439, M1439G, M1450, M1450G, M1451, M1451G, M3100, MS2174, PA-1510, PA-1538, PA-1539, PA1510, PA1538, PA1539, PA1550, PA2510, PA2548, PA3515, PA3553, PI 1505, PI 1537, PI 1556, PI 1557, PI 2512, PI 2515, PI 2530, PI 2540, PI 2550, PI1501, PI1505, PI1510, PI1536, PI1556, PI2512, PI2515, PI3525, PI3540, SI 1848, SI1848, V2045, V2055, V2060, V2065, V2085, V3050, V3505, V3515, XI 1546, XI 2428

**FujitsuSiemens AMILO PRO**

V2035, V2045, V2050, V2055, V2060, V2065, V2085, V3000, V3050, V3505, V3515, V3525, V3545, V8210

**Fujitsu Siemens CELSIUS**

H250, H265, H270

**Fujitsu Siemens ESPRIMO**

D9500, D9510, V5505, V5515, V5535, V6505, V6515, V6535, V6545, V6555

**Fujitsu Siemens ESPRIMO MOBILE**

D9510, V5505, V5515, V5535, V5545, V6505, V6515, V6535, X9510, X9515, X9525

**Fujitsu Siemens FMV-BIBLO**

NF40T, NF40U, NF40V, NF40W, NF40X, NF50W, NF50X, NF50X/V, NF55X, NF55X/D, NF60P, NF70T, NF70X, NF75X, NF75X/D, NF75Y, NFA40, NFB70

**Fujitsu Siemens LIFEBOOK**

A3110, A3120, A3130, A3210, A6010, A6020, A6025, A6030, A6110, A6120, A6240, C1300, C1300D, C1320, C1320D, C1321, C1410, C2000, C2210, E8200, E8220, E8310, E8410, E8420, N3410, N3430, N3510, N3511, N3520,

N3530, T2300, V1010, V1020, V700

**Gateway**

2412, 6010GZ, 6020GZ, 6021GZ, 6022GZ, 6023, 6510GZ, 6518GZ, 6520GZ, 6525, 6531GZ, 6800, 6832, 6834, 7000, 7110, 7210, 7215, 7305, 7310, 7312, 7320, 7322, 7324, 7325, 7326, 7330, 7405, 7410, 7415, 7422, 7425, 7426GX, 7430JP, 7508GX, 7510GX, E-475, M-1408, M-1410, M-1411, M-150, M-151, M-152, M-153, M-1600, M-1615, M-1617, M-1618, M-1619, M-1622, M-1624, M-1625, M-1628, M-1629, M-1631, M-1634, M-2404, M-2414, M-2623, M-2624, M-2625, M-2626, M-5822, M-6305, M-6306, M-6307, M-6308, M-6309, M-6315, M-6316, M-6317, M-6318, M-6319, M-6323, M-6333, M-6334, M-6337, M-6750, M-6752, M-6755, M-6801, M-6802, M-6804, M-6805, M-6808, M-6809, M-6810, M-6815, M-6816, M-6817, M-6821, M-6822, M-6824, M-6825, M-6826, M-6827, M-6828, M-6829, M-6833, M-6834, M-6840, M-6841, M-6843, M-6846, M-6847, M-6848, M-6849, M-6850, M-6862, M-6864, M-6866, M-6867, M-6873, M-6874, M-6878, M-6880, M-6881, M-6888, M-6889, M-6890, M-6890U, M-72, M-73, M-7301, M-7304, M-7305, M-7309, M-7315, M-7317, M-7320, M-7323, M-7325, M-7328, M-7332, M-7333, M-7334, M-7351, M-7356, M-78, M-7810, M-7815, M-7818, M-7819, M-7822, M1525, M1631, M200, M300, M360, M460, M465, M500, M505, M520, M5300, M600, M6305, M6306, M6307, M6308, M6309, M6312, M6315, M6316, M6317, M6318, M6319, M6337, M6421, M675, M6750, M6750H, M6752, M6755, M675CS, M68/22, M6801M, M6802M, M6804M, M6805M, M6808M, M6809M, M6810M, M6815, M6816, M6817, M6821B, M6823, M6823A, M6824, M6825J, M6826J, M6827, M6827J, M6828B, M6829B, M6834, M6839B, M6840J, M6841, M6843, M6846, M6847, M6848, M6849, M6864FX, M6864HFX, M6866, M6867, M6873H, M6874H, M6878, M6878H, M6880, M6881, MA3, MA7, ML6000, ML6227, ML6228, ML6230, ML6231, ML6232, ML6703, ML6714, ML6720, ML6721, ML6725, ML6731, ML6732, MP6925, MP6954, MT3305, MT6000, MT6015, MT6016, MT6017, MT6220, MT6223, MT6224, MT6225, MT6228, MT6229, MT6451, MT6452, MT6456, MT6457, MT6458, MT6459, MT6460, MT6700, MT6704, MT6705, MT6706, MT6707, MT6709, MT6722, MT6723, MT6728, MT6730, MT6733, MT6820, MT6821, MT6823, MT6825, MT6826, MT6827, MT6828, MT6830, MT6831, MT6832, MT6834, MT6835, MT6836, MT6838, MT6839, MT6840, MT6841, MT6842, MT6915, MT6916, MT6917, MT6919, MT6920, MX6000, MX6002, MX6003, MX6004, MX6005, MX6025, MX6027, MX6028, MX6030, MX6110, MX6111, MX6112, MX6113, MX6121, MX6123, MX6124, MX6128, MX6130, MX6131, MX6132, MX6134, MX6135, MX6136, MX6200, MX6211, MX6212, MX6213, MX6214, MX6215, MX6216, MX6217, MX6243, MX633H, MX6400, MX6410, MX6420, MX6421, MX6422, MX6423, MX6424, MX6425, MX6426, MX6427, MX6428, MX6429, MX6430, MX6431, MX6433, MX6436, MX6437, MX6438, MX6439, MX6440, MX6440H,

MX6441, MX6442, MX6444, MX6444H, MX6445, MX6446, MX6447, MX6448, MX6450, MX6452, MX6453, MX6454, MX6455, MX6468, MX6618, MX6619, MX6620, MX6625, MX6627, MX6627H, MX6628, MX6629, MX6629H, MX6630, MX6631, MX6632, MX6633, MX6633H, MX6635, MX6637, MX6638, MX6639, MX6640B, MX6641, MX6650, MX6708, MX6710, MX6750, MX6900, MX6901, MX6912, MX6915, MX6917, MX6918, MX6919, MX6920, MX6921, MX6922, MX6923, MX6924, MX6926, MX6927, MX6928, MX6930, MX6931, MX6932, MX6934, MX6935, MX6936, MX6937, MX6938, MX6939, MX6940, MX6941, MX6942, MX6943, MX6944, MX6945, MX6946, MX6947, MX6951, MX6952, MX6953, MX6954, MX6955, MX6956, MX6957, MX6958, MX6959, MX6960, MX6961, MX6991, MX7000, MX711, MX7118, MX7120, MX7122, MX7300, MX7315, MX7337, MX7340, MX7515, MX7517, MX7519, MX7519J, MX7520, MX7525, MX7527, MX7533, NX500, NX500S, NX500X, NX500XL, NX510S, NX510X, NX550X, NX550XL, NX560, NX560X, NX560XL, NX570, NX570S, NX570XL, S-7310, S-7320, S-7510, W650, W6501, W650A, W650I, W730

**Gateway SOLO**

6020GZ, 6518GZ, M460, MX6000, MX7000, NX560, NX5608

**Gigabyte**

N601, W511, W536, W551, W552, W566

**HP**

3730, 6710, 6715, 6720, 6730, 6735, 8510, NX7400, NX9000

**HP**

500, 510, 530, 550, 6710, 6715, 6715B, 6720, 8510P, C714, G3000, G3030, G3050, G50, G50-100, G50-102, G50-103, G50-104, G50-106, G50-108, G50-109, G50-111, G50-112, G50-113, G50-116, G50-118, G50-120, G50-121, G50-122, G50-123, G50-124, G50-126, G50-133, G50-201, G50-209, G50-211, G50-213, G50-215, G50-219, G5000, G6000, G7000

**HP BUSINESS NOTEBOOK**

530, 6710B, 6720S, 6730, 6735, NC8200, NC8230, NC8430, NX7000, NX7010, NX7100, NX7200, NX7300, NX7400, NX8200, NX8220, NX8420, NX9100, NX9105, NX9110, NX9500

**HP ELITEBOOK**

8530P, G50, G6000, G7000

**HP MEDIA CENTER**

G50-133US, G5000, G5050, G5052

**HP MOBILE WORKSTATION**

NW8000, NW8240, NW8440

**HP PAVILION**

5000DV, 6447, DV4-1444, DV4-1465, DV4000, DV4001, DV4002, DV4004, DV4005, DV4006, DV4007, DV4008, DV4009, DV4010, DV4011, DV4012, DV4013, DV4014, DV4015, DV4016, DV4017, DV4018, DV4019, DV4020, DV4021, DV4022, DV4023, DV4024, DV4025, DV4026, DV4027, DV4029, DV4030, DV4031, DV4040DV4043, DV4045, DV4046, DV4049, DV4050, DV4051, DV4052, DV4054, DV4056, DV4057, DV4060, DV4070, DV4073, DV4075, DV4078, DV4080, DV4085, DV4086, DV4100, DV4101, DV4102, DV4103, DV4104, DV4105, DV4106, DV4107, DV4108, DV4109, DV4110, DV4111, DV4112, DV4114, DV4115, DV4116, DV4117, DV4118, DV4120, DV4121, DV4122, DV4123, DV4124, DV4125, DV4126, DV4127, DV4128, DV4129, DV4130, DV4131, DV4134, DV4135, DV4136, DV4137, DV4138, DV4140, DV4142, DV4143, DV4145, DV4146, DV4149, DV4150, DV4151, DV4152, DV4153, DV4154, DV4155, DV4156, DV4158, DV4158, DV4159, DV4160, DV4161, DV4162, DV4163, DV4164, DV4165, DV4170, DV4176, DV4178, DV4180, DV4182, DV4199, DV4200, DV4201, DV4202, DV4203, DV4204, DV4205, DV4206, DV4207, DV4208, DV4209, DV4210, DV4211, DV4212, DV4213, DV4215, DV4217, DV4220, DV4223, DV4224, DV4225, DV4230, DV4234, DV4246, DV4250, DV4253, DV4257, DV4269, DV4270, DV4272, DV4273, DV4275, DV4288, DV4290, DV4295, DV4300, DV4301, DV4302, DV4303, DV4304, DV4305, DV4306, DV4307, DV4308, DV4309, DV4310, DV4312, DV4315, DV4318, DV4320, DV4321, DV4322, DV4325, DV4326, DV4327, DV4330, DV4334, DV4335, DV4336, DV4337, DV4339, DV4340, DV4342, DV4344, DV4346, DV4348, DV4350, DV4351, DV4353, DV4354, DV4356, DV4357, DV4358, DV4360, DV4363, DV4364, DV4365, DV4367, DV4368, DV4376, DV4378, DV4379, DV4381, DV4383, DV4384, DV4385, DV4386, DV4388, DV439, DV4391, DV4392, DV4394, DV4395, DV4396, DV4398, DV4400, DV4401, DV4405, DV4410, DV4419, DV4420, DV5, DV5-1000, DV5-1000T, DV5-1002, DV5-1003, DV5-1004, DV5-1007, DV5-1008, DV5-1010, DV5-1015, DV5-1017, DV5-1028, DV5-1034, DV5-1044, DV5-1050, DV5-1070, DV5-1100, DV5-1113, DV5-1115, DV5-1119, DV5-1119, DV5-1120, DV5-1125, DV5-1135, DV5-1138, DV5-1140, DV5-1235, DV5000, DV5000T, DV5001, DV5002, DV5003, DV5005, DV5006, DV5007, DV5008, DV5009, DV5010, DV5011, DV5012, DV5016, DV5017, DV5018, DV5020, DV5021, DV5022, DV5023, DV5024, DV5026, DV5027, DV5029, DV5030, DV5031, DV5033, DV5034, DV5035, DV5036, DV5037, DV5040, DV5041, DV5046, DV5047, DV5051, DV5052, DV5053, DV5054, DV5055, DV5056, DV5057, DV5058, DV5059, DV5061, DV5062, DV5063, DV5074, DV5075, DV5077, DV5078, DV5084, DV5088, DV5091, DV5092, DV5093, DV5094, DV5095, DV5096, DV5097, DV5098, DV5099, DV5100,

DV5101, DV5102, DV5103, DV5104, DV5105, DV5106, DV5107, DV5108,  
DV5109, DV5110, DV5111, DV5112, DV5113, DV5114, DV5115, DV5116,  
DV5117, DV5118, DV5119, DV5120, DV5121, DV5122, DV5123, DV5124,  
DV5125, DV5126, DV5127, DV5128, DV5129, DV5130, DV5131, DV5132,  
DV5133, DV5134, DV5135, DV5136, DV5137, DV5138, DV5139, DV5140,  
DV5142, DV5143, DV5144, DV5145, DV5147, DV5148, DV5149, DV5150,  
DV5156, DV5157, DV5158, DV5159, DV5160, DV5161, DV5162, DV5163,  
DV5164, DV5165, DV5166, DV5167, DV5170, DV5173, DV5175, DV5176,  
DV5177, DV5178, DV5179, DV5180, DV5184, DV5188, DV5189, DV5190,  
DV5191, DV5192, DV5193, DV5194, DV5195, DV5196, DV5197, DV5198,  
DV5199, DV5200, DV5201, DV5202, DV5203, DV5204, DV5205, DV5206,  
DV5207, DV5208, DV5209, DV5210, DV5211, DV5212, DV5213, DV5214,  
DV5215, DV5216, DV5217, DV5218, DV5219, DV5220, DV5221, DV5222,  
DV5223, DV5224, DV5225, DV5226, DV5227, DV5228, DV5229, DV5230,  
DV5231, DV5232, DV5233, DV5234, DV5235, DV5236, DV5237, DV5240,  
DV5252, DV5288, DV529, DV5290, DV5300, DV5T, DV5Z, DV6000, DV6001,  
DV6002, DV6003, DV6004, DV6005, DV6006, DV6007, DV6010, DV6011,  
DV6012, DV6013, DV6014, DV6015, DV6016, DV6017, DV6018, DV6019,  
DV6020, DV6021, DV6022, DV6023, DV6024, DV6025, DV6040, DV6045,  
DV6054, DV6057, DV6058, DV6059, DV6060, DV6061, DV6062, DV6063,  
DV6064, DV6065, DV6067, DV6086, DV6087, DV6088, DV6095, DV6097,  
DV6100, DV6101, DV6102, DV6103, DV6104, DV6105, DV6106, DV6107,  
DV6108, DV6109, DV6110, DV6111, DV6112, DV6113, DV6114, DV6115,  
DV6116, DV6117, DV6118, DV6119, DV6120, DV6121, DV6122, DV6123,  
DV6124, DV6125, DV6126, DV6127, DV6128, DV6129, DV6130, DV6131,  
DV6132, DV6133, DV6134, DV6135, DV6136, DV6137, DV6138, DV6139,  
DV6140, DV6141, DV6142, DV6143, DV6144, DV6145, DV6146, DV6147,  
DV6148, DV6149, DV6150, DV6151, DV6152, DV6153, DV6154, DV6155,  
DV6156, DV6157, DV6158, DV6159, DV6160, DV6161, DV6162, DV6163,  
DV6164, DV6165, DV6166, DV6167, DV6168, DV6169, DV6170, DV6171,  
DV6172, DV6173, DV6174, DV6175, DV6179, DV6180, DV6181, DV6182,  
DV6183, DV6184, DV6185, DV6186, DV6187, DV6188, DV6189, DV6190,  
DV6191, DV6195, DV6196, DV6197, DV6198, DV6199, DV6200, DV6201,  
DV6202, DV6203, DV6204, DV6205, DV6206, DV6207, DV6209, DV6210,  
DV6211, DV6212, DV6213, DV6214, DV6216, DV6219, DV6220, DV6221,  
DV6222, DV6224, DV6225, DV6226, DV6227, DV6228, DV6230, DV6231,  
DV6232, DV6233, DV6235, DV6237, DV6239, DV6240, DV6241, DV6243,  
DV6244, DV6245, DV6246, DV6247, DV6248, DV6251, DV6253, DV6254,  
DV6256, DV6258, DV6261, DV6263, DV6265, DV6266, DV6267, DV6269,  
DV6271, DV6277, DV6278, DV6280, DV6281, DV6282, DV6287, DV6288,  
DV6290, DV6291, DV6292, DV6298, DV6299, DV6300, DV6301, DV6302,  
DV6303, DV6304, DV6305, DV6306, DV6307, DV6308, DV6309, DV6310,  
DV6311, DV6312, DV6313, DV6314, DV6315, DV6316, DV6317, DV6318,



DV6319, DV6320, DV6321, DV6322, DV6323, DV6324, DV6325, DV6326, DV6327, DV6328, DV6329, DV6330, DV6331, DV6332, DV6333, DV6334, DV6335, DV6336, DV6337, DV6338, DV6339, DV6340, DV6341, DV6342, DV6343, DV6344, DV6345, DV6346, DV6347, DV6349, DV6350, DV6351, DV6352, DV6353, DV6354, DV6355, DV6356, DV6357, DV6358, DV6359, DV6360, DV6361, DV6362, DV6363, DV6364, DV6365, DV6366, DV6370, DV6372, DV6373, DV6374, DV6375, DV6376, DV6377, DV6378, DV6380, DV6382, DV6383, DV6384, DV6385, DV6386, DV6387, DV6388, DV6389, DV6390, DV6391, DV6395, DV6396, DV6397, DV6400, DV6401, DV6402, DV6403, DV6404, DV6405, DV6406, DV6407, DV6408, DV6409, DV6410, DV6412, DV6413, DV6415, DV6416, DV6418, DV6420, DV6422, DV6423, DV6424, DV6425, DV6426, DV6427, DV6428, DV6429, DV6433, DV6435, DV6436, DV6439, DV6444, DV6445, DV6446, DV6447, DV6448, DV6449, DV6450, DV6451, DV6458, DV6460, DV6465, DV6470, DV6500, DV6501, DV6502, DV6503, DV6504, DV6505, DV6507, DV6508, DV6509, DV6510, DV6530, DV6531, DV6532, DV6535, DV6536, DV6537, DV6538, DV6539, DV6540, DV6541, DV6542, DV6543, DV6544, DV6545, DV6546, DV6547, DV6548, DV6549, DV6558, DV6560, DV6563, DV6565, DV6570, DV6589, DV6600, DV6601, DV6602, DV6603, DV6604, DV6605, DV6607, DV6609, DV6610, DV6611, DV6612, DV6613, DV6614, DV6615, DV6616, DV6617, DV6618, DV6619, DV6620, DV6621, DV6622, DV6623, DV6624, DV6625, DV6626, DV6627, DV6628, DV6629, DV6630, DV6631, DV6636, DV6640, DV6646, DV6650, DV6655, DV6660, DV6662, DV6680, DV6690, DV6700, DV6707, DV6715, DV6733, DV6770, DV6780, DV6800, DV6809, DV6810, DV6815, DV6820, DV6830, DV6833, DV6835, DV6838, DV6900, DV6910, DV6915, DX6000, DX6500, DX6600, DX6650, DX6670, G50, G60, G6060, ZD7000, ZD7001, ZD7005, ZD7900, ZT3000, ZT3001, ZT3007, ZT3010, ZT3011, ZT3012, ZT3013, ZT3014, ZT3015, ZT3016, ZT3017, ZT3018, ZT3019, ZT3020, ZT3021, ZT3022, ZT3023, ZT3024, ZT3025, ZT3026, ZT3027, ZT3028, ZT3029, ZT3030, ZT3031, ZT3032, ZT3033, ZT3034, ZT3035, ZT3036, ZT3037, ZT3038, ZT3039, ZT3040, ZT3041, ZT3042, ZT3043, ZT3044, ZT3045, ZT3046, ZT3047, ZT3048, ZT3049, ZT3050, ZT3051, ZT3057, ZT3068, ZT3100, ZT3101, ZT3105, ZT3106, ZT3110, ZT3111, ZT3113, ZT3114, ZT3115, ZT3116, ZT3120, ZT3130, ZT3131, ZT3140, ZT3170, ZT3200, ZT3201, ZT3202, ZT3203, ZT3204, ZT3205, ZT3206, ZT3207, ZT3208, ZT3209, ZT3210, ZT3211, ZT3212, ZT3213, ZT3214, ZT3215, ZT3216, ZT3217, ZT3218, ZT3219, ZT3220, ZT3221, ZT3222, ZT3223, ZT3224, ZT3225, ZT3228, ZT3229, ZT3230, ZT3231, ZT3232, ZT3235, ZT3236, ZT3237, ZT3239, ZT3240, ZT3241, ZT3242, ZT3250, ZT3260, ZT3280, ZT3300, ZT3301, ZT3302, ZT3303, ZT3305, ZT3306, ZT3307, ZT3308, ZT3309, ZT3310, ZT3311, ZT3312, ZT3313, ZT3314, ZT3315, ZT3316, ZT3317, ZT3318, ZT3320, ZT3321, ZT3322, ZT3325, ZT3328, ZT3330, ZT3331, ZT3335, ZT3338, ZT3339, ZT3340,

ZT3341, ZT3342, ZT3346, ZT3349, ZT3350, ZT3351, ZT3355, ZT3368,  
ZT3370, ZT3377, ZT3380, ZT3400, ZT3418, ZT3449, ZT3460, ZT3465,  
ZV5000, ZV5001, ZV5002, ZV5003, ZV5004, ZV5006, ZV5007, ZV5008,  
ZV5011, ZV5012, ZV5013, ZV5014, ZV5015, ZV5016, ZV5017, ZV5018,  
ZV5019, ZV5022, ZV5023, ZV5024, ZV5025, ZV5026, ZV5030, ZV5034,  
ZV5037, ZV5045, ZV5100, ZV5101, ZV5102, ZV5103, ZV5110, ZV5111,  
ZV5112, ZV5116, ZV5117, ZV5119, ZV5120, ZV5121, ZV5123, ZV5124,  
ZV5125, ZV5126, ZV5128, ZV5131, ZV5132, ZV5133, ZV5134, ZV5136,  
ZV5137, ZV5139, ZV5140, ZV5141, ZV5142, ZV5143, ZV5159, ZV5160,  
ZV5161, ZV5166, ZV5167, ZV5168, ZV5169, ZV5171, ZV5172, ZV5173,  
ZV5175, ZV5178, ZV5180, ZV5185, ZV5187, ZV5188, ZV5191, ZV5196,  
ZV5200, ZV5201, ZV5202, ZV5203, ZV5204, ZV5205, ZV5206, ZV5207,  
ZV5208, ZV5209, ZV5211, ZV5212, ZV5213, ZV5214, ZV5215, ZV5217,  
ZV5218, ZV5219, ZV5220, ZV5221, ZV5222, ZV5223, ZV5224, ZV5225,  
ZV5226, ZV5227, ZV5228, ZV5229, ZV5230, ZV5231, ZV5232, ZV5233,  
ZV5234, ZV5235, ZV5240, ZV5242, ZV5245, ZV5246, ZV5247, ZV5250,  
ZV5255, ZV5257, ZV5260, ZV5261, ZV5265, ZV5267, ZV5268, ZV5269,  
ZV5270, ZV5271, ZV5272, ZV5280, ZV5287, ZV5290, ZV5300, ZV5304,  
ZV5308, ZV5310, ZV5320, ZV5323, ZV5325, ZV5326, ZV5327, ZV5328,  
ZV5329, ZV5330, ZV5331, ZV5340, ZV5342, ZV5343, ZV5346, ZV5347,  
ZV5348, ZV5357, ZV5358, ZV5359, ZV5360, ZV5362, ZV5364, ZV5365,  
ZV5366, ZV5367, ZV5368, ZV5369, ZV5370, ZV5371, ZV5372, ZV5373,  
ZV5374, ZV5375, ZV5376, ZV5377, ZV5378, ZV5379, ZV5380, ZV5381,  
ZV5383, ZV5385, ZV5386, ZV5390, ZV5400, ZV5401, ZV5402, ZV5403,  
ZV5404, ZV5405, ZV5407, ZV5410, ZV5413, ZV5415, ZV5417, ZV5420,  
ZV5422, ZV5430, ZV5440, ZV5442, ZV5443, ZV5445, ZV5450, ZV5454,  
ZV5455, ZV5456, ZV5460, ZV5464, ZV5466, ZV5470, ZV5475, ZV5476,  
ZV5495, ZV6000, ZV6001, ZV6003, ZV6005, ZV6006, ZV6007, ZV6008,  
ZV6009, ZV6010, ZV6011, ZV6013, ZV6015, ZV6017, ZV6020, ZV6024,  
ZV6025, ZV6026, ZV6027, ZV6028, ZV6029, ZV6061, ZV6062, ZV6064,  
ZV6065, ZV6066, ZV6067, ZV6068, ZV6069, ZV6090, ZV6100, ZV6107,  
ZV6115, ZV6123, ZV6130, ZV6131, ZV6150, ZV6153, ZV6156, ZV6170,  
ZV6179, ZV6180, ZV6181, ZV6195, ZV6200, ZV6201, ZV6203, ZV6209,  
ZV6223, ZV6230, ZV6233, ZV6270, ZX5000, ZX5001, ZX5003, ZX5005,  
ZX5008, ZX5011, ZX5012, ZX5020, ZX5022, ZX5030, ZX5035, ZX5037,  
ZX5038, ZX5039, ZX5040, ZX5041, ZX5042, ZX5043, ZX5044, ZX5045,  
ZX5049, ZX5050, ZX5051, ZX5052, ZX5060, ZX5065, ZX5070, ZX5078,  
ZX5100, ZX5109, ZX5113, ZX5128, ZX5129, ZX5148, ZX5149, ZX5151,  
ZX5170, ZX5171, ZX5180, ZX5190, ZX5200, ZX5201, ZX5202, ZX5245,  
ZX5260, ZX5265, ZX5270, ZX5273, ZX5275, ZX5280, ZX5295, ZX5300,  
ZX5316, ZX5369

**HP PRECISION**

6700

**IBM THINKPAD**

2529, 2530, 2531, 2532, R500, R61, SL500, SL500, T500, T60, T60P, T61, W500, Z60, Z60M, Z61, Z61M, Z61P

**Lenovo**

R500

**Lenovo 3000**

C100,C200,N100,N200,N201,Y100,Y410,Y410N,Y500

**Lenovo IDEAPAD**

4051,530Y, 7758, Y510, Y530

**Lenovo THINKPAD**

R500, R60, R60I, R61, R61E, R61I, SL500, T60, T60P, T61, T61P, W500, Z60, Z61E, Z61M, Z61P

**Lenovo THINKPAD 3000**

6466, G530, N100, N200, N500, T61, LG, LW60, R500, S1

**LG ELECTRONICS**

E500, LW60, P1, R510, S1, S510, X57, X58

**LG PRO EXPRESS**

F1, P1

**Packard Bell EASYNOTE**

4014, A5340, A7, A7145, A7718, A8, A8202, A8550, B3, B3312, B3605, B3800, BG46, BU45, C3, C3205, C3223, C3227, C3255, C3265, C3300, C3302, D5, E1, E1245, E2, E2310, E2315, E2316, E2532, E2540, E2560, E3, E3242, E3245, E3265, E3314, E4, E4710, E4715, E5, E5138, E5142, E5146, E6, E6100, E6307, E6310, ENMH36, F5, F5275, F5277, F5280, F5281, F5287, F7, F7280, F7300, F7305, G1, G1340, G1350, GN45, H5, H5315, H5535, J2, J2301, K5, K5266, K5283, K5285, K5305, L4, L4014, M3, M3325, M5, M5255, M5262, M5263, M5265, M5284, M7, M7305, MB55, MB66, MB88, MB89, ME35, MH35, ML61, MT85, MV35, MV45, MV46, MV51, MV85, MX37, MX45, MX52, MX61, MZ35, MZ36, P7735, R0, R0422, R1, R1000, R1004, R1005, R1801, R1910, R1935, R1938, R1994, R3321, R4, R4250, R4360, R4622, R4650, R5, R7175W, R7735, R8, R8720, R8740, R8770, R9, R9200, R9250, R9252, S4, S4, S4802, S4935, S4947, S4996, SB88, SJ51, SW51, T5, T5135, V5, V5908, V7, V7801, VX, VX3650, VX4514, VX5014,

VX6014, W1, W1801, W3240, W3301, W3910

**Packard Bell I POWER**

5254, 5264, 5305, 5541, 5542

**Packard Bell IGO**

2000, 2142, 2185, 2440, 2461, 2491, 3000, 3203, 3491, 4000, 4450, 4451, 5000, 5453, 5461, 5581, 6000, 6203, 6204

**Samsung**

40, AL-096, NP-R40, NP-R50, NP-X50, NTR55, NX30, P510, P560, R40, R50, R509, R510, R55, R60, R70, X30, X50, X60

**Samsung SENS**

R510, R60, R60P

**Sony VAIO**

FS745P, PCG-415S, PCG-7E1, PCG-K215, PCG-K215M, PCG-K23, PCG-K23Q, PCG-K25, PCG-K27, PCG-K315, PCG-K33, PCG-K35, PCG-K37, PCG-K415, PCG-K45, PCG-K47, VGC-53, VGC-LB50, VGC-LB52, VGC-LB53, VGC-LJ52, VGC-M51, VGN-130P, VGN-140B, VGN-160, VGN-180, VGN-210, VGN-270E, VGN-29, VGN-39, VGN-6AAPSR, VGN-A115, VGN-A115Z, VGN-A140, VGN-A140P, VGN-A150, VGN-A160, VGN-A190F, VGN-A215, VGN-A240, VGN-A240B, VGN-A250, VGN-A260, VGN-A290, VGN-A290F, VGN-A295, VGN-A51, VGN-AS33, VGN-AS34, VGN-AS53, VGN-AS54, VGN-BX196, VGN-BX196-SP, VGN-BX296, VGN-BX396, VGN-BX41, VGN-BX4AANS, VGN-BX4AAPS, VGN-BX51, VGN-BX560, VGN-BX560B, VGN-BX561, VGN-BX563, VGN-BX565, VGN-BX567, VGN-BX60, VGN-BX61, VGN-BX660, VGN-BX665, VGN-BX665P, VGN-BX6AANS, VGN-BX6AAPS, VGN-BX760, VGN-BX94, VGN-BX96, VGN-BXAAPSB, VGN-BZ11, VGN-BZ12, VGN-BZ13, VGN-BZ21, VGN-BZ562, VGN-BZ569P44, VGN-BZ569P45, VGN-BZ569P46, VGN-BZ569P47, VGN-BZ570, VGN-BZ6YANZ, VGN-F214, VGN-F2240, VGN-FE11, VGN-FE15, VGN-FE15GP, VGN-FE20, VGN-FE21, VGN-FE28, VGN-FE31, VGN-FE31B, VGN-FE32, VGN-FE33, VGN-FE39, VGN-FE41, VGN-FE48, VGN-FE49, VGN-FE50, VGN-FE51, VGN-FE52, VGN-FE53, VGN-FE590, VGN-FE650, VGN-FE660, VGN-FE670, VGN-FE690, VGN-FE730, VGN-FE770, VGN-FE770G, VGN-FE780, VGN-FE790, VGN-FE855, VGN-FE8550, VGN-FE865, VGN-FE869, VGN-FE870, VGN-FE870E, VGN-FE880, VGN-FE880E, VGN-FE890, VGN-FE890N, VGN-FE90, VGN-FE91, VGN-FE92, VGN-FE92NS, VGN-FE92S, VGN-FS115, VGN-FS115E, VGN-FS15, VGN-FS15CP, VGN-FS15CP, VGN-FS18, VGN-FS18CP, VGN-FS18CP, VGN-FS18GP, VGN-FS195, VGN-FS20, VGN-FS21, VGN-FS215, VGN-FS215S, VGN-FS215Z, VGN-FS22, VGN-FS25, VGN-FS25CP, VGN-FS28, VGN-FS285, VGN-FS28C, VGN-FS28CP, VGN-FS295, VGN-FS30, VGN-FS31, VGN-FS315, VGN-FS32, VGN-FS33, VGN-

FS395, VGN-FS415, VGN-FS43, VGN-FS45P, VGN-FS485, VGN-FS485B, VGN-FS495, VGN-FS50, VGN-FS500, VGN-FS500B, VGN-FS500P, VGN-FS500P12, VGN-FS51, VGN-FS515, VGN-FS52, VGN-FS520, VGN-FS520B, VGN-FS53, VGN-FS530B, VGN-FS540, VGN-FS540P, VGN-FS550, VGN-FS550F, VGN-FS570, VGN-FS595, VGN-FS620, VGN-FS625, VGN-FS625B, VGN-FS630, VGN-FS630W, VGN-FS635, VGN-FS635B, VGN-FS640, VGN-FS645, VGN-FS645P, VGN-FS660, VGN-FS675, VGN-FS675P, VGN-FS680, VGN-FS690, VGN-FS730, VGN-FS730W, VGN-FS740, VGN-FS742, VGN-FS745, VGN-FS750, VGN-FS750P, VGN-FS760, VGN-FS770, VGN-FS775, VGN-FS775P, VGN-FS780, VGN-FS790, VGN-FS810, VGN-FS830, VGN-FS840, VGN-FS850, VGN-FS875, VGN-FS875P, VGN-FS890, VGN-FS8900, VGN-FS90, VGN-FS91, VGN-FS92, VGN-FS920, VGN-FS940, VGN-FS980, VGN-FS990, VGN-FT31, VGN-FT32, VGN-FT50, VGN-FT51, VGN-FT52, VGN-FT53, VGN-FT73, VGN-FT90, VGN-FT91, VGN-FT92, VGN-FT93, VGN-FZ11, VGN-FZ130, VGN-FZ140, VGN-FZ160, VGN-FZ18, VGN-FZ180, VGN-FZ19, VGN-FZ190, VGN-FZ21, VGN-FZ210, VGN-FZ2340, VGN-FZ240, VGN-FZ250, VGN-FZ280, VGN-FZ283, VGN-FZ285, VGN-FZ29, VGN-FZ290, VGN-FZ31, VGN-FZ32, VGN-FZ340, VGN-FZ38, VGN-FZ39, VGN-FZ440, VGN-FZ51, VGN-FZ52, VGN-FZ61, VGN-FZ62, VGN-FZ70, VGN-FZ71, VGN-FZ72, VGN-FZ90, VGN-FZ91, VGN-FZ92, VGN-J31, VGN-K31, VGN-K71, VGN-LB53, VGN-LB92, VGN-LJ52, VGN-N11, VGN-N130, VGN-N130G, VGN-N140, VGN-N140F, VGN-N150, VGN-N150P, VGN-N170, VGN-N170G, VGN-N19, VGN-N19VP, VGN-N21, VGN-N21M, VGN-N220, VGN-N220E, VGN-N230, VGN-N230E, VGN-N230N, VGN-N250, VGN-N250E, VGN-N250N, VGN-N270, VGN-N29, VGN-N31, VGN-N320, VGN-N325, VGN-N325E, VGN-N350, VGN-N365, VGN-N370, VGN-N38, VGN-N380, VGN-N385, VGN-N395, VGN-N50, VGN-N51, VGN-NR10, VGN-NR11, VGN-NR110, VGN-NR120, VGN-NR160, VGN-NR180, VGN-NR21, VGN-NR22, VGN-NR220, VGN-NR240, VGN-NR260, VGN-NR285, VGN-NR31, VGN-NR310, VGN-NR32, VGN-NR330, VGN-NR350, VGN-NR38, VGN-NR385, VGN-NR430, VGN-NR460, VGN-NR485, VGN-NR498, VGN-NR50, VGN-NR51, VGN-NR52, VGN-NR71, VGN-NR72, VGN-NS10, VGN-NS11, VGN-NS110, VGN-NS12, VGN-NS130, VGN-NS135, VGN-NS20, VGN-NS21, VGN-NS240, VGN-NS31, VGN-NS38, VGN-NS50, VGN-S2240

**Toshiba DYNABOOK**

AX, AX/53C, AX/53D, AX/54C, AX/55C, AX/55D, AX/57A, AX/730LS, L40, PA AX940LS, TX, TX/65D, TX/66D, TX/67D, TX/68D, TX/745LS, TX/760LS, TX/770LS, TX/850LS, TX/860LS, TX/880LS, TX/950LS, TX/960LS, V9, VX, VX1

**Toshiba DYNABOOK QOSMIO**

F10, F20, F30, F40, F40W

**Toshiba DYNABOOK SATELLITE**

AW5, AW6, K10, K11, K15, K16, K17, K20, P1W, T30, T31, TXW, TXW/66AW, TXW/66CW, TXW/66DW, TXW/67AW, TXW/67CW, TXW/67DW, TXW/69AW, TXW/69CW, TXW/69DW

**Toshiba EQUIUM**

A100, A100-147, A100-549, A110, A200, A200-196, A200-1AC, A210, A300D, L300, L40, M40-149, M40X, M40X-103, M40X-189, M40X-230, M40X-S149, M70, M70-173

**Toshiba QOSMIO**

A200-1AA, F10, F10-100, F10-105, F10-106, F10-114, F10-121, F10-124, F10-125, F10-130, F10-132, F15, F20, F20-110, F20-130, F25, F30, F35-AV205, F40, F45, F50, G15, G15-AV501

**Toshiba SATEGO**

A100

**Toshiba SATELLITE**

100-512, 8135-S4527, A100, A104, A105, A110, A130, A135, A15, A20, A200, A200-180, A200-18T, A200-19K, A200-1A9, A200-AB, A202, A205, A210, A215, A25, A300, A300D, A305, A350D, A70, A75, L30, L300, L300D, L305, L305D, L35, L355D, L40, L45, M1530, M30, M30X, M35, M35X, M40, M40U, M40X, M45, M500, M70, MX40, P10, P15, PSAA57, PSAA8A, PSAA9A, PSAA9U, PSAAOU, PSM43U, SM30

**Toshiba SATELLITE PRO**

100, 1200, A100, A120, A120SE, A200, A200GE, A200HD, A200SE, A210, A300, A300D, L30-115, L300, L300D, L40, M30, M300, M35, M40, M40X, M45, M70, S10, S200, S300, S300M

**Toshiba TERCA**

A10, A205, A4, A7, A8, A9, M40X, S10, S5

**Unwill**

250EN1, 257SA, 257SA1, 258KA, 258KA0, 258KA5, 259EN1, 259EN3, 259II0, 259II1, 755SI4, L51AI, L51II

17.1"  
1440\*900  
PIXELS  
GLOSSY  
WXGA LCD

**Acer ASPIRE**

1800, 1801, 1802, 1804, 5800, 7000, 7003, 7100, 7103, 7104, 7110, 7111, 7112, 7113, 7500, 7512, 7520, 7720, 7730, 9300, 9301, 9302, 9303, 9400, 9402, 9404, 9410, 9411, 9412, 9413, 9420, 9423, 9425, 9500, 9501, 9502, 9503, 9504, 9505, 9510, 9513, 9520, 9521, 9524, 9525

**Acer EMACHINE**

G520, G620, M6807

**Acer EXTENSA**

7120, 7220, 7420, 7620, 7630

**Acer TRAVELMATE**

5000, 5104, 5110, 5600, 5602, 5610, 5614, 5620, 5623, 6593, 7230, 7330, 7520, 7530, 7720, 7730

**Apple POWERBOOK**

A1013, A1052, A1085, A1107, A1139

**Apple POWERBOOK G4**

17 INCH

**ASUS**

F7SR, G2SQ, G2SV, G70, G71, M70, W2JB, W2W, X71

**Compaq PRESARIO**

A90, A91, A902, A903, A904, A905, A909, A910, A913, A915, A916, A918, A920, A924, A925, A928, A930, A931, A933, A934, A935, A936, A938, A939, A940, A942, A944, A945, A948, A949, CQ70, CQ70-100, CQ70-120, X6000, X6001, X6050, X6070, X6100, X6105, X6110, X6125

**Dell INSPIRON**

1705, 1720, 1721, 9200, 9300, 9400, 9500, E1705, GEN2

**Dell PRECISION**

M6300, M6400, M90

**Dell STUDIO**

1735, 1737, S17

**Dell VOSTRO**

1700, 1710, 1720

**Dell XPS**

GEN 2, M170, M1710, M1730

**Fujitsu Siemens AMILO**

A-3667G, A3667, A3667G, LI 1818, LI 1820, LI 3910, LI-1818, LI-1820, M-3438, M-4438, M3438, M4438, PI3625, X-4438, XA 1526, XA 1527, XA 2528, XA 2529, XA 3530, XA-1526, XA-2528, XA-2529, XI 1526, XI 1546, XI

1547, XI 1554, XI 2528, XI 2550, XI-1547, XI-1554, XI-2528, XI-2550

**Fujitsu Siemens FMV-BIBLO**

NB60LW, NX90X, NX95XD

**Fujitsu Siemens LIFEBOOK**

N6000, N6010, N6100, N6110, N6120, N6200, N6210, N6220, N6400, N6410, N6420, N6460, N6470

**Fujitsu Siemens LIFEBOOK N SERIES**

N6000, N6010, N6100, N6110, N6120, N6210, N6220, N6410, N6420, N6460

**Gateway**

8510, 8515, 8550, M675, M680, M685, MP8708, MP8708, MP8709, MP8709, MX8000, MX8520, MX8523, MX8525, MX8528, MX8530, MX8554, MX8556, MX8570, MX8707, MX8708, MX8709, MX8710, MX8711, MX8712, MX8714, MX8715, MX8716, MX8720, MX8721, MX8734, MX8738, MX8739, MX8741, NX850, NX860, P-170, P-171, P-172, P-173, P-6301, P-6302, P-6311, P-6313, P-6318U, P-6822, P-6825, P-6828, P-6829, P-6832, P-6860, P172S, PA6, S-7410, S-7510, S-7700, S-7710

**HP**

DV8125NR, DV9043EA, G70

**HP**

6820S, 6830S, 8710P, 8710W, NX6320, NX9420, NX9600

**HP BUSINESS NOTEBOOK**

6830S, NX9420, NX9500, NX9600

**HP MOBILE WORKSTATION**

NW9440

**HP PAVILION**

6280S, 700, 9208, DV1300, DV6000, DV6100, DV6149, DV7, DV7-1000, DV7-1100, DV7-1134, DV7-1243, DV7-1245, DV7-1285, DV7000, DV7T, DV7T-1000, DV7T-1100, DV7Z, DV7Z-1000, DV7Z-1100, DV8000, DV8002, DV8005, DV8010, DV8013, DV8013CL, DV8025, DV8026, DV8027, DV8028, DV8029, DV8030, DV8035, DV8040, DV8040CA, DV8045, DV8048, DV8050, DV8051, DV8075, DV8088, DV8088US, DV8089, DV8099, DV8100, DV8102, DV8110, DV8113, DV8114, DV8116, DV8117, DV8120, DV8125, DV8130, DV8133, DV8135, DV8140, DV8155, DV8173, DV8175, DV8176, DV8177, DV8178, DV8179, DV8195, DV8197, DV8199, DV81XXUS, DV8200, DV8201,



DV8202, DV8203, DV8204, DV8205, DV8206, DV8207, DV8208, DV8209,  
DV8210, DV8211, DV8212, DV8213, DV8214, DV8215, DV8216, DV8217,  
DV8218, DV8220, DV8221, DV8222, DV8223, DV8225, DV8226, DV8227,  
DV8228, DV8229, DV8230, DV8231, DV8232, DV8233, DV8235, DV8240,  
DV8251, DV8252, DV8253, DV8254, DV8256, DV8260, DV8261, DV8263,  
DV8275, DV8279, DV8280, DV8283, DV8284, DV8285, DV8286, DV8287,  
DV8288, DV8289, DV8290, DV8291, DV8292, DV8293, DV8294, DV8295,  
DV8296, DV8297, DV8298, DV8299, DV8300, DV8301, DV8302, DV8304,  
DV8305, DV8306, DV8307, DV8308, DV8309, DV8310, DV8311, DV8312,  
DV8313, DV8314, DV8315, DV8316, DV8317, DV8318, DV8320, DV8321,  
DV8322, DV8323, DV8324, DV8325, DV8327, DV8328, DV8330, DV8333,  
DV8335, DV8336, DV8338, DV8339, DV8345, DV8356, DV8357, DV8365,  
DV8369, DV8370, DV8372, DV8373, DV8375, DV8377, DV8378, DV8379,  
DV8380, DV8382, DV8387, DV8389, DV8390, DV8391, DV8392, DV8393,  
DV8394, DV8395, DV8396, DV8397, DV8398, DV8399, DV8400, DV8408,  
DV8460, DV8500, DV8531, DV9000, DV9001, DV9002, DV9003, DV9004,  
DV9005, DV9006, DV9007, DV9008, DV9009, DV9010, DV9013, DV9015,  
DV9016, DV9018, DV9023, DV9024, DV9030, DV9033, DV9035, DV9040,  
DV9044, DV9047, DV9054, DV9057, DV9060, DV9074, DV9075, DV9076,  
DV9077, DV9078, DV9080, DV9081, DV9083, DV9084, DV9086, DV9089,  
DV9091, DV9092, DV9093, DV9094, DV9095, DV9096, DV9097, DV9098,  
DV9099, DV9100, DV9179, DV9200, DV9201, DV9202, DV9203, DV9204,  
DV9205, DV9206, DV9207, DV9208, DV9209, DV9210, DV9211, DV9212,  
DV9213, DV9216, DV9217, DV9218, DV9219, DV9220, DV9230, DV9231,  
DV9232, DV9233, DV9235, DV9241, DV9243, DV9244, DV9253, DV9260,  
DV9265, DV9267, DV9271, DV9272, DV9273, DV9275, DV9276, DV9285,  
DV9287, DV9289, DV9291, DV9293, DV9294, DV9295, DV9296, DV9297,  
DV9299, DV9300, DV9303, DV9305, DV9307, DV9308, DV9309, DV9310,  
DV9311, DV9313, DV9314, DV9315, DV9317, DV9318, DV9319, DV9320,  
DV9324, DV9330, DV9332, DV9334, DV9335, DV9339, DV9340, DV9342,  
DV9343, DV9344, DV9345, DV9346, DV9347, DV9348, DV9351, DV9374,  
DV9379, DV9380, DV9381, DV9385, DV9400, DV9407, DV9408, DV9410,  
DV9413, DV9417, DV9418, DV9420, DV9424, DV9428, DV9429, DV9438,  
DV9443, DV9500, DV9501, DV9502, DV9503, DV9505, DV9507, DV9509,  
DV9510, DV9515, DV9517, DV9518, DV9519, DV9520, DV9521, DV9522,  
DV9525, DV9530, DV9532, DV9533, DV9534, DV9535, DV9540, DV9542,  
DV9543, DV9545, DV9547, DV9548, DV9555, DV9562, DV9565, DV9571,  
DV9574, DV9575, DV9580, DV9585, DV9588, DV9592, DV9595, DV9596,  
DV9599, DV9600, DV9601, DV9602, DV9603, DV9604, DV9605, DV9606,  
DV9607, DV9608, DV9610, DV9611, DV9612, DV9613, DV9614, DV9615,  
DV9616, DV9617, DV9618, DV9620, DV9623, DV9625, DV9626, DV9627,  
DV9628, DV9629, DV9630, DV9634, DV9635, DV9638, DV9639, DV9640,  
DV9644, DV9645, DV9646, DV9649, DV9650, DV9653, DV9655, DV9657,

DV9658, DV9660, DV9665, DV9670, DV9675, DV9680, DV9681, DV9682, DV9684, DV9685, DV9686, DV9687, DV9690, DV9691, DV9694, DV9695, DV9698, DV9700, DV9701, DV9702, DV9703, DV9704, DV9705, DV9706, DV9708, DV9709, DV9710, DV9711, DV9712, DV9713, DV9714, DV9715, DV9717, DV9718, DV9719, DV9720, DV9721, DV9722, DV9723, DV9724, DV9725, DV9726, DV9727, DV9728, DV9729, DV9730, DV9731, DV9734, DV9736, DV9740, DV9743, DV9744, DV9747, DV9748, DV9750, DV9758, DV9778, DV9800, DV9810, DV9815, DV9817, DV9819, DV9820, DV9823, DV9824, DV9825, DV9827, DV9830, DV9831, DV9834, DV9838, DV9843, DV9847, DV9850, DV9858, DV9860, DV9900, DV9917, G70, G70-120, G70-212, G70-250, G70-257, G70-T, NW9440, ZD7000, ZD7001, ZD7005, ZD7010, ZD7015, ZD7020, ZD7030, ZD7040, ZD7048, ZD7050, ZD7058, ZD7100, ZD7101, ZD7102, ZD7140, ZD7160, ZD7168, ZD7180, ZD7188, ZD7198, ZD7200, ZD7201, ZD7230, ZD7249, ZD7259, ZD7269, ZD7300, ZD7310, ZD7340, ZD7374, ZD7379, ZD7389, ZD7395, ZD8000, ZD8001, ZD8002, ZD8003, ZD8004, ZD8005, ZD8007, ZD8008, ZD8009, ZD8010, ZD8011, ZD8015, ZD8017, ZD8019, ZD8020, ZD8030, ZD8042, ZD8043, ZD8044, ZD8045, ZD8047, ZD8050, ZD8051, ZD8052, ZD8053, ZD8055, ZD8060, ZD8070, ZD8072, ZD8075, ZD8076, ZD8078, ZD8079, ZD8080, ZD8100, ZD8101, ZD8105, ZD8110, ZD8111, ZD8112, ZD8115, ZD8120, ZD8122, ZD8123, ZD8124, ZD8125, ZD8129, ZD8130, ZD8135, ZD8139, ZD8147, ZD8148, ZD8150, ZD8151Z, D8155, ZD8156, ZD8157, ZD8158, ZD8159, ZD8160, ZD8162, ZD8179, ZD8180, ZD8181, ZD8182, ZD8183, ZD8184, ZD8185, ZD8200, ZD8201, ZD8203, ZD8204, ZD8205, ZD8210, ZD8214, ZD8215, ZD8217, ZD8218, ZD8219, ZD8220, ZD8223, ZD8224, ZD8225, ZD8226, ZD8230, ZD82XXUS, ZD8305, ZD8318, ZD8320, ZD9215

**HP PRESARIO CQ70**

CQ70-130

**Lenovo IDEAPAD**

Y710, Y730

**Lenovo THINKPAD**

W700, W710

**LG EXPRESS**

LW70, LW75, R700, R710, W1

**Packard Bell EASYNOTE**

SB65, SB85, SB86, SB88, SB89, SJ51, ST8, SW51-200, SW61, W3332, W3333, W3450, W3450W

**Samsung**

M40, M55, R700, R710

**Samsung R SERIES**

NP-R710

**Sony VAIO**

VGN-600, VGN-A217, VGN-A270, VGN-A317, VGN-A397, VGN-A417, VGN-A517, VGN-A600, VGN-A61, VGN-A617, VGN-A62, VGN-A63, VGN-A72, VGN-A73, VGN-AR11, VGN-AR11B, VGN-AR130, VGN-AR150, VGN-AR16, VGN-AR170, VGN-AR21, VGN-AR21B, VGN-AR230, VGN-AR230G, VGN-AR25, VGN-AR250, VGN-AR270, VGN-AR31, VGN-AR31E, VGN-AR320, VGN-AR320E, VGN-AR41, VGN-AR41E, VGN-AR41L, VGN-AR50, VGN-AR51, VGN-AR51E, VGN-AR51J, VGN-AR52, VGN-AR520, VGN-AR520E, VGN-AR53, VGN-AR54, VGN-AR55, VGN-AR550, VGN-AR61, VGN-AR61E, VGN-AR61M, VGN-AR630, VGN-AR630E, VGN-AR64, VGN-AR65, VGN-AR660, VGN-AR660U, VGN-AR69, VGN-AR690, VGN-AR690U, VGN-AR70, VGN-AR70B, VGN-AR71, VGN-AR710, VGN-AR78, VGN-AR80, VGN-AR81, VGN-AR82, VGN-AR83, VGN-AR84, VGN-AR85, VGN-AR88, VGN-AR92, VGN-AX517, VGN-AX570, VGN-AX580

**Toshiba DYNABOOK**

WX/3727CDS

**Toshiba DYNABOOK QOSMIO**

G10, G20, G30

**Toshiba DYNABOOK SS**

RX1/S7A

**Toshiba EQUIUM**

L350, P200, P300

**Toshiba QOSMIO**

G10, G15, G20, G30, G35, X300, X305

**Toshiba SATEGO**

P100, P200, X200

**Toshiba SATELLITE**

L350, L350D, L355, L355D, L40, LS60, M60, M65, P100, P105, P20, P200, P200D, P205, P205D, P25, P30, P300, P300D, P305, P305D, P33, P35, PSPAOU-180068, SP30E, X200, X205

	<p><b>Toshiba SATELLITE PRO</b> L350, M60, P100, P200, P300, P300D</p> <p><b>Unwill</b> X72IA</p>
<p>18.4" 1680*945 PIXELS GLOSSY HD LCD 1 CCFL</p>	<p><b>Acer Aspire</b> 8930 series, 8930G, 8930G-864G64BN, 8930G-644G32MN, 8930-6243, 8930G-643G25MN, 8930G-904G100BWN, 8930G-664G32MN, 8930G-584G32BN, 8930G-654G32MN, 8930-6247, 8930G-9A4G100WN, 8930G-904G32BN, 8930G-864G32Bn, 8930G-734G32BN, 8930G-644G50BN, 8930G-944G64BN, VGN-AW11Z/B, 8930G-844G64BN, 8930G-844G32BN, 8930G-744G64BN, 8530 Series, 8530G, 8530G-724G32MN, 8530G-754G32MN, 8530, 8530G-724G64MN, 8920 series, 8920G, 8920, 8730 series, 8735 series, 8735ZG, 8730G, 8730, 8920G-6A3G25BN, 8735G, 8920G-934G64BN, 8920G-6A4G32BN, 8730G-644G32MN, 8920G-834G32Bn, 8735ZG-444G64MN, 8735ZG-443G32MN, 8730G-864G50MN, 8730G-6681, 8730G-6042, 8730-6550, 8920G-932G32Bn, 8735ZG-454G64MN, 8735ZG-444G50MN, 8930G-844G82WN, 8930G-734G64BN, 8930G-654g25Mn, 8930G-644G50BN8, 8920G-934G50Bn, 8920-6671, 8920-6048, 8920-6030, 8735G-664G100MN, 8735, 8730ZG-424G32MN, 8730ZG-34G32MN, 8730ZG-344G32Mn, 8730ZG, 8730-6951, 8730-6918, 8730-6314</p> <p><b>Fujitsu Siemens Amilo</b> Xi3650, Pi3660</p> <p><b>Packard Bell EasyNote</b> DT85-CT-005, DT85 series</p> <p><b>Sony VAIO</b> VGN-AW series, VGN-AW21S/B, VGN-AW11M/H, VGN-AW11XU/Q, VGN-AW21M/H, VGN-AW190NCB, VGN-AW110J, VGN-AW41JF/H, VGN-AW31M/H, VGN-AW190NKH, VGN-AW41ZF/B, VGN-AW31XY, VGN-AW290JFQ, VGN-AW190Y, VGN-AW190, VGN-AW180Y, VGN-AW130J, VGN-AW11SR/B, VGN-AW11S/B, VGN-AW110N/H, VGN-AW110N, VGN-AW41MF/H, VGN-AW31S/B, VGN-AW290YFB, VGN-AW290JQH, VGN-AW290JPB, VGN-AW290JAH, VGN-AW270Y/Q, VGN-AW270Y/Q, VGN-AW235J/B, VGN-AW21XY/Q, VGN-AW21VY/Q, VGN-AW1RXU/Q, VGN-AW190YDB, VGN-AW190YCB, VGN-AW190YBB, VGN-AW190YAB, VGN-AW190U, VGN-AW190NIH, VGN-AW190NDB, VGN-AW190NBB, VGN-AW190NAB, VGN-AW190N, VGN-AW190JAH, VGN-AW190JAB, VGN-</p>

	<p>AW190J, VGN-AW190E, VGN-AW180Y/Q, VGN-AW310J/H, VGN-AW290YPH</p> <p><b>Toshiba Satellite</b>  P500 series, P500-1GN, P500, P500-ST5801, P500-1C8, P500-ST68X2, P500-ST6821, P500-ST5807, P500-ST5806, P500-ST2G02, P500-ST2G01, P500-1D7, P500-12E, P500-12D, P500-125, P500-026, P500-025, P500-024, P500-01R, P500-01C, P505D</p> <p><b>Toshiba Qosmio</b>  G50 series, G50-13J, G50-12G, G50-115, G50-102, G50-13Q, G50-127, G50-10i, G50-10H, G55, X505</p>
<p>18.4"  1920*1080  PIXELS  FULL HD  WUXGA  WITH 2  CCFL LCD</p>	<p><b>Acer ASPIRE</b>  8920, 8920G, 8930, 8943</p> <p><b>ASUS</b>  N90SV-A2, NX90JQ, W90</p> <p><b>Fujitsu Siemens Amilo</b>  Xi3650, Li3910-NR003</p> <p><b>HP PAVILION</b>  DV8T, DV8-1200 series, dv8-1200ed</p> <p><b>Sony VAIO</b>  AW11SB, AW310-1</p> <p><b>Toshiba QOSMIO</b>  X500, X505</p>